



Assembly Instructions

4 BURNER GAS GRILL WITH SEARING SIDE BURNER



720-1126C
ITM. / ART. 1807190













19001133A0

Table of Contents

Package Parts List	2
Tools Needed	5
Hardware Pack List	5
Assembly Instructions	6


USE OUTDOORS ONLY

Package Parts List

<p>1</p> 	<p>2 (x2)</p> 
<p>3 (x2) (lock icon)</p> 	<p>4</p> 
<p>5</p> 	<p>6</p> 
<p>7</p> 	<p>8</p> 
<p>9</p> 	<p>10</p> 

Package Parts List


11



12 (x2)




13



14




15



16



17




18



19



20



Package Parts List


21 (x4)




22 (x2)




23




24




25




26



27



28




29



30




Tools Needed




Some parts come with screws pre-installed. Loosen and tighten for final assembly.

Hardware Pack List


Truss Head Screw
1/4 - 20 x 5/8"




Truss Head Screw
5/32 - 32 x 3/8 "



Flat Washer
1/4"




Flat Washer
5/32"




Assembly Instructions


1 !




2




3




4







5




6










11




12







15




16







17




18











23





24




25



26



27




28


B

x1


29





29





30




31




32




33




34




35




36





37




38






Cooking grid configurations

1




2



3




4




Side Burner Cooking Grid Configurations

1



2



Costco Wholesale UK Ltd /
Costco Online UK Ltd
Hartspring Lane
Watford, Herts
WD25 8JS
United Kingdom
01923 213113
www.costco.co.uk

Limited warranty provided by manufacturer
Garantie limitée fournie par le fabricant.
Garantía limitada proporcionada por el fabricante

Made in China
Fabriqué en Chine
Hecho en China

720-1126C

2024 Costco Wholesale Corporation. All rights reserved.
Tous droits réservés
Todos los derechos reservados.

11/24
Printed in China
Imprimé en Chine
Impreso en China