



## Twin Socket Adaptors with 4x USB Chargers Instructions

1. Plug socket adaptor into a wall socket connected to the mains supply.
2. Make sure electronic equipment is turned off before plugging it into the wall socket.
3. Unit provides surge protection up to 450 Joules.
4. A glowing blue indicator light shows that surge protection is being provided. Check indicator light periodically (see NOTE).

### NOTE:

• This device features an internal protection that will disconnect the surge-protective component at the end of its useful life, but will maintain power to the load — now unprotected.

• If the blue “protected” indicator light goes out, this unit will no longer provide surge protection as intended and should be replaced. This device is not a lightning arrestor, so it will not afford protection when lightning strikes nearby, power lines, the house, service entrance or antennas.

5. 4.2-Amp max output allows you to charge two tablets, or one tablet and two smartphones, or four smartphones, at full capacity at the same time. Recharge your device at a maximum speed of 2.1 Amp when connected to a single port.

**NOTE: USB charging ports may not charge all devices. Some devices require a proprietary USB power supply.**

A removable 13A fuse is built into this socket adaptor. For replacement instructions, please visit our website [www.cesmarthome.com](http://www.cesmarthome.com).

### USB Indicator Feature:

LED color changes to indicate the charging status of your devices charged through the USB ports.

- Red — Charging
- Green — Device(s) charged
- Light will change from Red to Green when the device is 95-97% charged and remain Green until fully charged.


### Specifications:

Open Circuit Voltage of the Combination Wave Generator	6KV (L-N)
Joule Rating	450J
Line Voltage	220~240 V ~50/60Hz
Maximum Line Current	13Amp
Maximum Continuous Operating Voltage	255V~
Voltage Protection Level	1.5KV (L-N)
3-wire Grounding Outlets	2
USB Charging Ports	Four 5VDC/4.2 Amp Total Output

This product is designed to limit damage to electronic devices from electrical surges of less than 450 joules. The sensitivity of electronic devices to electrical surges varies, and this product may not protect against electrical surges of greater than 450 joules, such as from lightning strikes. Please consult the manufacturer of devices plugged into this product and/or a licensed electrician to confirm appropriate protection levels.

LIMITED ONE YEAR MANUFACTURERS WARRANTY. ALL CHARGING ESSENTIALS PRODUCTS MUST BE INSTALLED AND USED IN ACCORDANCE WITH THEIR INSTRUCTIONS, INCLUDING INSTRUCTIONS PROVIDED WITH THE CHARGING ESSENTIALS PRODUCT PACKAGING OR PROVIDED ON THE PRODUCT ITSELF. CHARGING ESSENTIALS SURGE SUPPRESSION PRODUCTS WILL NOT PREVENT DAMAGE FROM ALL SURGES, AND SPECIFICALLY ARE NOT DESIGNED OR WARRANTED TO PROTECT AGAINST LIGHTNING STRIKES. CHARGING ESSENTIALS SURGE SUPPRESSION PRODUCTS MUST BE INSTALLED ON A PROPERLY GROUNDED 13AMP WALL SOCKET WITH A CIRCUIT BREAKER APPROPRIATE FOR ELECTRONIC PRODUCTS.

AT THE DISCRETION OF CHARGING ESSENTIALS, ANY DEFECTIVE PRODUCT WILL BE REPLACED OR THE PURCHASE PRICE REFUNDED. THIS WARRANTY SHALL IN NO EVENT EXCEED AMOUNTS PAID BY CUSTOMER TO CHARGING ESSENTIALS OR ITS AFFILIATES FOR THE CHARGING ESSENTIALS PRODUCTS INVOLVED, AND EXPRESSLY EXCLUDES COVERAGE OF ANY DAMAGE TO THIRD PARTY PRODUCTS OR ELECTRONICS.



**CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, USE ONLY INDOORS.** UNIT SHOULD BE PLUGGED INTO AN INTERIOR GROUNDED WALL SOCKET CONNECTED TO THE MAINS POWER SUPPLY. NOT INTENDED FOR USE WITH RCD SOCKETS. TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT USE THIS DEVICE WITH A SOCKET IN WHICH THE SLOT OPENINGS DO NOT ALIGN WITH THE BLADES.

### SAFETY WARNING:

Keep out of reach of children. For indoor use only. Do not plug in an appliance where the load exceeds 13A. Always ensure the plug of any appliance is fully inserted into the socket. Do not use if the casing of the socket becomes cracked or damaged. Failure to follow these instructions could result in fire, electric shock, injury or damage to persons, product or property and will invalidate the warranty.

### RECYCLING:



This symbol is known as the “Crossed-out Wheeled Bin” Symbol. This symbol on the product(s) and / or accompanying documents means that used electrical and electronic products should not be mixed with general household waste. Some chemicals contained within electrical/electronic products can be harmful to health and the environment.

Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling.

For proper treatment, recovery and recycling, please take this product(s) to designated collection points. Please contact your local authority for further details of your nearest designated collection point.

MADE IN CHINA

CHARGING ESSENTIALS - Bloomington, MN USA

CUSTOMER SERVICE: +448081967800 M-F 3:00 p.m. – 10:00 p.m. GMT (9:00 a.m. – 4:00 p.m. USA Central) / English, French

Email: Visit [www.cesmarthome.com](http://www.cesmarthome.com) and click “Contact Us”.