


DREO

Smart TurboPoly Fan
565S

USER MANUAL



//

Thanks for Choosing **DREO!**

Your support means the world to us.
We hope you enjoy our product as much as
we did creating it.

CONTENT

01

ASSEMBLING YOUR
APPLIANCE

1-3

02

CONNECTING TO
YOUR APPLIANCE

4

03

KNOWING YOUR
APPLIANCE

5-6

04

USING YOUR
APPLIANCE

7-10

05

CLEANING AND
MAINTENANCE

11-13

06

TROUBLESHOOTING

14-15


ASSEMBLING YOUR APPLIANCE

01

Assembly Instructions

When using the appliance for the first time, remove the wraps and attach the parts by following the steps below.

1




Turn the fan body upside down.

2




Install the short pedestal into the fan body.

3




Push the column into the base, then screw through the flat washer, and into the bottom of the column.

4




Raise or lower the appliance to the desired height.

5



Install the remote control holder.





CAUTION

Do not operate the appliance if the base has not been installed.

Please exercise caution and handle the base with care during installation.

Package Contents



CONNECTING TO YOUR APPLIANCE

02



Before connecting the appliance to your mobile device, please scan the QR code on the left or go to the app store and search "DREO", then select and download the app.



Look for "TurboPoly Fan 565S" when connecting your new appliance.



You can use the DREO app to connect your appliance to **Amazon Alexa** or **Google Home**. Please follow the in-app instructions to set up your voice assistant.

NOTE: You must create a DREO account to access voice assistants.

- 1 Launch DREO and sign in or create account by following in-app instructions.
- 2 Enable Bluetooth on your mobile device and plug in your appliance.
- 3 Hold  for 5 seconds to start WiFi connection settings. (Tip: The WiFi icon  will keep flashing when pairing.)
- 4 Tap+ **Add Device** and select **TurboPoly Fan 565S**.
- 5 Follow in-app instructions to complete WiFi connection.
- 6 You're now ready to control the appliance on your app. (Tip: To restart connection settings, hold  again for 5 seconds)

KNOWING YOUR APPLIANCE

03

Control Panel



Power Button

- Turn power on/off.



Fan Speed Button (1-9 Levels - Turbo)

- Long press for 3 seconds to start timer settings.



Ambient Light Button (On/Off)

- Long press for 3 seconds to mute/unmute.



Ambient Light Color Button



Vertical Oscillation Button

- Sweep airflow vertically (0°/60°/90°/120°).



Horizontal Oscillation Button

- Sweep airflow horizontally (0°/30°/60°/90°/120°).
- Long press 5 seconds to start network settings and device pairing.

Note:

- Long press  and **RGB** for 5 seconds to restore factory settings.
- Long press  and  for 10 seconds to turn off/on WiFi connection and enter/exit Low Power Standby Mode.
- When turned off, display will show  while your fan is resetting to its original position. You can enable/disable this feature by long pressing  for 3 seconds.

LED Display



Auto Mode



Turbo Mode



WiFi Connection



Fan Speed/Timer
Hour



Vertical
Oscillation



Horizontal
Oscillation




Timer

USING YOUR APPLIANCE

04


Getting the Most out of Your Appliance



Summer:

Use with Air Conditioner


Position the air circulator in front of your AC to circulate cold air and provide better cooling.



Winter:

Use with Heater

Send the heat to the corner of the room and circulate warm air faster.



Spring & Fall:

Circulation

Make the indoors as fresh and pleasant as the outdoors.

Working Modes

(You can switch modes through the DREO app)



Normal Mode

Fan runs at the fixed speed.



Auto Mode

Fan automatically increases speed when the room temperature is higher and decreases speed when the temperature is lower.



Turbo Mode

Fan runs at the maximum speed.



Natural Mode

(Available in the DREO app)

Fan speed goes up and down intermittently to replicate the natural breeze.



Custom Mode

(Available in the DREO app)

Fan speed changes according to temperatures or time you desire.



Sleep Mode

(Available in the DREO app)

Balance comfort and noise by automatically decreasing fan speed as you fall asleep.

If the fan speed is higher than 4, it will decrease two times, one speed every 30 minutes, then it will remain constant.

If the fan speed is 3 or below it will remain constant.

Unlock custom light effects with the DREO app



Breath: Light dims up and down for a calming effect.



Constant: Light remains unchanged, ideal for providing a steady background light.



Circle: Light cycles through different colors, ideal for small parties or gaming setups.

Additional Features



Timer

When the fan is ON/OFF, touch the timer button  on the remote control repeatedly to set a timer from 0 to 8 hours. When the timer ends, the fan will stop/start running automatically. To cancel, set the time to 0 hour.

Note: When the auto off timer is enabled, display will return to fan speed after 3 seconds.



Child Lock

Long press  and  at the same time for 3 seconds to turn on/off Child Lock.

Note: Child Lock doesn't apply to operations from the remote control. You can also turn off Child Lock by re-plugging in, or resetting to factory settings.



Memory

If the fan is turned OFF or disconnected from power, it will operate under the previous settings (except the Timer setting) when it is turned ON again.



Countdown Display

When long pressing buttons for Factory Reset, Child Lock, and Mute, a countdown will show on the display accordingly.



Firmware Update

Check the firmware version on the DREO app and update regularly for the air circulator to work more efficiently.

 Display will show "U" during the update process.
Do not operate until the update is completed.




Display Auto Off

Display turns off after 1 minute (after 5 seconds in sleep mode). Wake up the display with any button.

To disable this feature, please go to the DREO app.


Remote Control



The remote control has no RF circuit.

CLEANING AND MAINTENANCE

05



Outer Surface

Gently wipe off the dust with a soft, dry cloth.

Base

The base can be disassembled in the reverse order of assembly.

CAUTION




1. Always unplug the fan before any cleaning or maintenance to avoid the risk of fire, electric shock, or injury to persons.
2. Do not immerse in water or get water inside the motor housing.
3. Do not use any chemical agents when cleaning the fan.
4. Store in a cool, dry place and cover it to protect from dust.



WARNING


To reduce the risk of electrical shock and injury to persons, turn off and unplug the appliance before any cleaning and maintenance.

1




Remove the screw on the front grille, rotate the grille counterclockwise to take off.

2




Remove the blade cap by rotating it as shown and take the blade assembly out of the shaft.

3




Rinse cap, blades, and grille under running water or with a clean, damp cloth.

4



Dry up all parts, and insert the blade assembly back into the shaft by aligning the centers.

5



- ① Align the point on the front grille with the right point on the casing.
- ② Rotate the grille clockwise and install the screw back in place.

My appliance won't turn on!

Make sure that the cord is connected to a powered outlet and the mains voltage corresponds with the voltage indicated on the appliance.

My appliance is shaky and wobbling!

1. Place the appliance on a flat, level surface.
2. Incorrect installation might also cause shakiness. Please refer to the assembly instructions in **page 1-2**.

My appliance is making vibration and noise!

1. Place the appliance on a flat, level surface.
2. Be sure not to insert anything into the air inlet and outlet.

If your problem is not listed or still persists, please contact our Customer Support (see page 15).

Model No.: DR-HPF025S
Rev_1.0_UK

We're Here to Help!

 uk-support@dreo.com

 www.dreo.com



www.dreo.com

Looking for help?

Contact us to get expert support.



uk-support@dreo.com



www.dreo.com