

USER MANUAL

FUNCTIONAL TRAINER



by Pure-Tec LimitedNovember 2020



CONGRATULATIONS

You've just taken the first step to a healthier and stronger body. This multi-gym by Inspire offers the key to unlocking your body's potential. Regular strength training on a multi-gym has been shown to deliver a host of benefits including: increased muscle tone, decreased body fat, improved energy levels, a reduction in stress, and improved cardiac output. Once again, congratulations, you are on your way to improving your self image, overall health, and quality of life.

BEFORE ASSEMBLING YOUR HOME GYM

IMPORTANT: Read this entire manual before attempting to build or use this machine. This manual contains step by step instructions for proper assembly.

Use the parts list included in this manual to verify that all parts are accounted for before assembly. If any parts are missing, contact the retailer of this multi-gym for replacement parts.

Make sure that adequate room has been cleared before attempting to build your multi-gym. A rubber mat is recommended for use under your

multi-gym to protect wood flooring or carpeting from damage during assembly and usage.

This multi-gym is intended for indoor use only. Rust can form on certain parts including guide rods in a humid environment, resulting in impaired function.

Service of your multi-gym should only be performed by an authorized Inspire retailer. Service performed by anyone else can result in loss of warranty. If you need help finding an authorized retailer, please contact us directly:



Email

service@puretecfitness.com

Pg. 2 V1.0



TABLE OF CONTENTS

IMPORTANT SAFETY NOTICE PRECAUTIONS	4
TOOLS REQUIRED FOR ASSEMBLY	4
HARDWARE SIZING CHART	5
FUNCTIONAL TRAINER ASSEMBLY INSTRUCTIONS	8
DECAL PLACEMENT	12
GENERAL MAINTENANCE INFORMATION	13
MAINTENANCE SCHEDULE	13
LIMITED WARRANTY	14
PARTS LIST	15

REGISTER WARRANTY ONLINE

To register your product for warranty, visit www.puretecfitness.com



IMPORTANT SAFETY NOTICE PRECAUTIONS

This exercise machine is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble or operate your machine. In particular, note the following safety precautions:

- 1. Keep children and pets away from the machine at all times. DO NOT leave children unattended in the same room with the machine.
- 2. Only one person at a time should use the machine.
- 3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. Consult a Physician.
- 4. Position the machine on a clear, leveled surface. Do not use outdoors.
- 5. Keep hands away from all moving parts.
- 6. Always wear appropriate workout clothing when exercising. Running or aerobic shoes are also required when using the machine.
- 7. Use the machine only for its intended use as described in this manual.
- 8. Disabled persons should not use the machine without a qualified person or physician in attendance.
- 9. Always do stretching exercises to properly warm up before using machine.
- 10. Never operate the machine if it is not functioning properly.
- 11. A spotter is recommended during exercise.


TOOLS REQUIRED FOR ASSEMBLY

Tools Required for Assembling the Machine: Adjustable Wrench and Allen Wrenches. NOTE: Two or more people assembling this machine is a must. DO NOT attempt to assemble this machine alone

Pg. 4 V1.0




HARDWARE SIZING CHART




Pg. 5 V1.0





Pg. 6 V1.0






Pg. 7 V1.0



FUNCTIONAL TRAINER ASSEMBLY INSTRUCTIONS

STEP 1

- A. Do not tighten the Nuts and Bolts until instructed to do so.
- B. Place the Lower Cross Brace (#4) between the Right & Left Stations (#1 & #2) in the mid-span.
- C. Attach one end of the Lower Cross Brace to the Right Station. Secure it with two M10 x 70 Allen Bolts (#19) four Ø 10 Washers (#25), and two M10 Aircraft Nuts (#24). Repeat the same procedure to install the other side.
- D. Repeat Procedure **B & C** to install the Upper Cross Brace **(#5)**.
- E. Place the Pull Up Bar Assembly (#3) on top of the Right and Left Stations.
- F. Secure each end with two M10 x 25 Allen Bolts (#20), two Ø 10 "Lock Washers (#23), and Ø 10 Washers (#25).
- G. Securely tighten all Nuts and Bolts installed.



Pg. 8 V1.0





STEP 2


- A. Install Guide Rods (#7) into holes on bottom Frame using M10 x 80 Allen Bolt (#18) and Ø 10 Spring Washers (#25). Tighten bolts now.
- B. Install Rubber Bumpers (#16) on each Guide Rod (#7). Slide fifteen 10lb Weight Plates (#10) from the top of Guide Rods (#7) down to the Rubber Bumpers (#16). Make sure the weight sticker cut out is facing the inside of the machine.
- C. Remove the two M10 x 19 Allen Bolts (#21), Ø 10 Spring Washers (#23), and Ø 10 Washers (#25) which were preassembled in the factory to hold the Guide Rod Bracket (#6). Slide the Selector Stem Assembly (#8) onto the Guide Rods (#7). Install Large Pulley (#30) and wrap the cable between the U-shaped Pulley Bracket (#27) using the M10 x 2 (#29) Allen Bolt located on the Selector Steam Assembly (#8).
- D. Hold the Selector Stem Assembly (#8) above the weight stack to make it easier to install Guide Rod Bracket (#6) on Guide Rods (#7).
- E. Once the Guide Rod Bracket (#6) is installed onto the Guide Rods (#7), Push the Guide Rod Bracket back into the upright.
- F. Secure the Bracket back to the upright frame with the two M10 x 19 Allen Bolts (#21), Ø 10 lock Washers (#23), Ø 10mm Washers (#25).
- G. Lower the Selector Stem down onto the top of the weight stack.
- H. Check all the cables to make sure they are on track on the pulleys.
- I. Peel off the weight resistance label from the Resistance Label Set (#26) and attach to the plates.
- J. Insert the Weight Selector Pin (#9) into the weight stack.
- K. Lubricate the Guide Rods with super lube or lube provided in Hardware Pack.
- L. If Needed, Adjust the Cable tension by first loosening the M10 x 2 (#29) Allen Bolt located on the Selector Steam Assembly (#8) then rotate the Tension Adjustment Plate (#28) clock or counterclockwise to move the Bolt and the Large Pulley (#30) up and down along the open track inside the U-shaped Pulley Bracket (#27). Once desired tension is achieved, securely tighten the Bolt (#29) back.
- M. Repeat the Procedure A through N above to install the other set of weight plates to the Left Station. (#2)


Pg. 9 V1.0












Pg. 10 V1.0



STEP 3


- A. Attach the Height Adjustment Handle (#15) to the Left Lock Switch (#32) on the Pulley Carriage. (Not shown on diagram) And secure it with one M5 x 10 Allen Bolt (#22). Repeat the same procedure to install the other side.
- B. Connect the Single Handle (#13) to the Cable (#1) on the Right Station (#1) with a Spring Clip (#17). Repeat the same procedure to install the other side.
- C. Lift up the Height Adjustment Handle (#15) and slide the Pulley Carriage along the Pulley Carriage Support Frame to the selected level. Release the Handle to lock the Pulley Carriage in position.
- D. Store Curl Bar (#12), and Rope (#11) onto the Hanger Bracket behind the Upper Cross Brace (#5). Hang Chin Up Belt (#14) on Upper Cross Brace (#5).



Pg. 11 V1.0



DECAL PLACEMENT



Pg. 12 V1.0



GENERAL MAINTENANCE INFORMATION

- Periodically inspect the cables for splitting, cracking or fraying. Also, watch for bulging or flat areas in the cable.
- · Immediately replace cables at the first signs of damage or wear. Never use equipment with damaged or worn cables.
- · Cables naturally stretch over time, so check cable slack periodically and adjust cable tension as needed.
- Regularly inspect product for loose hardware.
- Do not use or store equipment outdoors.
- Inspect snap links, swivels, handles, and weight stack pins for wear or damage. If wear or damage exists, replace immediately.
- Locate and familiarize yourself with all warning decals on the multi-gym.
- · Replace damaged or worn upholstery immediately.
- Periodically wipe down guide rods with a dry cloth and re-apply a thin coat of a Teflon-based lubricant.

MAINTENANCE SCHEDULE

ROUTINE	HOME MAINTENANCE	ENTRY DATE					
Inspect: Links, Pull Pins, Spring Clips, Swivels, Weight Stack Pins	WEEKLY						
Clean: Upholstery	WEEKLY						
Inspect: Cables and their Fittings	WEEKLY						
Inspect: Tautness of all Shrouds	WEEKLY						
Inspect: Accessory Bars and Handles	3 MONTHS						
Inspect: All Decals	3 MONTHS						
Inspect: All Nuts and Bolts. Tighten if Needed	3 MONTHS						
Inspect: Anti-Skid surfaces	3 MONTHS						
Clean and Lubricate: Guide Rods with a Teflon based lubricant	3 MONTHS						
Lubricate: Seat Sleeves and all Plastic Slides	3 MONTHS						
Clean and Wax: All Glossy Finishes	YEARLY						
Replace: Cables, Belts and Connecting Parts	2 YEARS						

Pg. 13 V1.0



LIMITED WARRANTY

This Warranty applies to Inspire Strength products manufactured or distributed by Pure-Tec Ltd.

CONSUMER USE:

LIMITED LIFETIME FRAME:	LIMITED LIFETIME PARTS:	LIMITED LIFETIME MOVING PARTS:		
Includes Frame and Welds	Includes Upholstery, Hardware, etc.	Includes Pulleys, Cables, etc.		

PLEASE NOTE THIS INSPIRE PRODUCT IS NOT MADE FOR COMMERCIAL USE

Using a non-commercial product in a commercial setting can result in serious injury or death!

Pure-Tec Limited warrants that the Product you have purchased for light-commercial, personal, family or household use from Pure-Tec Limited or from an authorized Pure-Tec Limited reseller is free from defects in materials or workmanship under normal use during the warranty period. Your sales receipt, showing the date of purchase of the Product, is your proof of the date of purchase. This warranty extends only to you, the original purchaser. It is not transferable to anyone who subsequently purchases the Product from you. It excludes expendable parts such as paint and finish. This Warranty becomes VALID ONLY if the Product is assembled / installed according to the instructions / directions included with the Product.

Replacement and repair of parts

During the warranty period Pure–Tec Limited will, at no additional charge, repair or replace the Product if it becomes defective, malfunctions, or otherwise fails to conform with this Warranty under normal light-commercial, personal, family, or household use. In repairing the product Pure–Tec Limited may replace defective parts with, at the option of Pure–Tec Limited, serviceable used parts that are equivalent to new parts in performance, or new parts. All exchanged parts and Products replaced under this warranty will become the property of Pure–Tec Limited. Pure–Tec Limited reserves the right to change manufacturers and or specification of any part to cover any existing warranty.

Service procedures

To obtain warranty parts, you must return the parts to Pure-Tec Limited or an authorized Pure-Tec Limited retailer in its original container (or equivalent). You must pre-pay any shipping charges, taxes, or any other charges associated with transportation of the Product. In addition, you are responsible for insuring any Product shipped or returned. You assume the risk of loss during shipment. You must present Pure-Tec Limited with proof-of-purchase documents (including the date of purchase, Model, and Serial Number). Any evidence of alteration, erasing or forgery of proof -of-purchase documents will be cause to void this Warranty. Register your warranty online visit www. puretecfitness.com

Conditions and Exceptions

This Warranty does not extend to any Product not purchased from Pure-Tec Limited or from unauthorised Pure-Tec Limited reseller. This Warranty does not extend to any Product that has been damaged or rendered defective; (a) as a result of accident, misuse, or abuse; (b) by the use of parts not manufactured or sold by Pure-Tec Limited; (c) by modification of the Product; (d) as a result of service by anyone other than Pure-Tec Limited, or an authorized Pure-Tec Limited warranty service provider; (e) product that has not been properly maintained (follow maintenance schedule found on product). Should any product submitted for Warranty service be found to be ineligible, an estimate of repair cost will be furnished and the repair will be made if requested by you upon Pure-Tec Limited receipt of payment or acceptable arrangement of payment.

Disclaimer

EXCEPT AS EXPRESSLY SET FORTH IN THIS WARRANTY PURE-TEC LIMITED MAKES NO OTHER WARRANTIES; EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. PURE-TEC LTD EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS WARRANTY. NEITHER PURE-TEC LIMITED NOR ANY OF ITS AFFILIATES SHALL BE RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. PURE-TEC LIMITED IS NOT RESPOSIBLE FOR THE REPAIR OR REPLACEMENT OF ANY PARTS THAT PURE-TEC LIMITED DETERMINES HAVE BEEN SUBJECTED AFTER THE DATE OF MANUFACTURE TO ALTERATION, NEGLECT, ABUSE, MISUSE, NORMAL WEAR & TEAR, ACCIDENT, DAMAGE DURING TRANSIT OR INSTALLATION, FIRE, FLOOD, OR ANY ACT OF GOD. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU. This Warranty gives you specific legal rights and you may also have other rights that may vary from state to state. This is the only express warranty applicable to Pure-Tec Ltd's "Inspire" branded strength products, Pure-Tec Limited neither assumes nor authorizes anyone to assume for it any other express warranty.

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Pg. 14 V1.0



PARTS LIST

No.	Description	Part Number	Qty.			
1	Right Station Assembly	GM692200408PZ	1			
2	Left Station Assembly	GM692200409PZ	1			
3	Upper Frame Assembly	GM692220002PZ02	1			
4	Lower Cross Brace	GM690260001PT0105	1			
5	Upper Cross Brace	GM692300004PT0105	1			
6	Guide Rod Bracket & Ring Cap	GM692381001PT0105 GM692-881-002	2			
7	Guide Rod	GM692-381-002	4			
8	Selector Stem Assembly	GM692500003PZ10	2			
9	Weight Selector Pin	GM692-500-004	2			
10	Weight Plate		30			
11	Rope	GM692-881-011	1			
12	Curl Bar	GM691320003PZ02	1			
13	Single Handle	GM660820001WX07	2			
14	Chin Up Belt	GM692-400-005SK	1			
15	Height Adjustment Handle	GM691-880-003SK	2			
16	Rubber Bumper	GM692-881-003	4			
17	Hook	0200-070-082	2			
18	M10 x 80 Allen Bolt	0113-210-806	4			
19	M10 x 70 Allen Bolt	0113-210-708	8			
20	M10 x 25 Allen Bolt	0113-210-258	4			
21	M10 x 19 Allen Bolt	0113-210-208	4			
22	M5 x 10 Allen Bolt	0113-705-088	2			
23	Ø 10 Lock Washer	0116-310-028	8			
24	M10 Aircraft Nut	0110-710-008	8			
25	Ø 10 Washer	0116-210-508	28			
26	Resistance Label Set	GM692-900-001	2			
27	U-shaped Pulley Bracket	GM692-500-002	2			
28	Ø 2" Tension Adjustment Plate	GM690-501-006	2			
29	M10 x 2" Allen Bolt	0113-210-508	2			
30	Pulley	GM692-880-001	2			
31	Right Lock Switch	GM690-320-003	1			
32	Left Lock Switch	GM690-320-004	1			
	Tool List					
33	#6 Allen Wrench (Tool)	0511-606-03	1			
34	#4 Allen Wrench (Tool)	0511-604-01	1			
35	14#&17# Wrench (Tool)	M330-561-002	1			

Pg. 15 V1.0



USER MANUAL

FLB2C FOLDING ADJUSTABLE BENCH



by Pure-Tec Limited November 2020



IMPORTANT SAFETY NOTICE

PRECAUTIONS

This exercise bench is built for optimum safety. However, certain precautions apply whenever you use a piece of exercise equipment. Be sure to read the entire manual before you assemble or use your bench. In particular, note the following safety precautions:

- 1. Keep children and pets away from the bench at all times.
- 2. Only one person at a time should use the bench.
- 3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. Consult a Physician.
- 4. Position the bench on a clear, leveled surface. Do not use outdoors.
- 5. Keep hands away from all moving parts.
- 6. Always wear appropriate workout clothing when exercising. Running or aerobic shoes are also required when using the bench.
- 7. Use the bench only for its intended use as described in this manual.
- 8. Disabled persons should not use this bench without a qualified person or physician in attendance.
- 9. Always do stretching exercises to properly warm up before using this bench.
- 10. Never use this bench if it is not functioning properly.
- 11. A spotter is recommended during exercise.
- 12. Maximum **USER** weight on bench is 136 kg / 300 lb. This means that a **PERSONS** maximum weight can be up to 136 kg / 300 lb. **The total weight capacity that the bench can hold is 226.8 kg / 500 lb**.

CARE AND MAINTENANCE

- 1. Regularly inspect product for loose hardware.
- 2. Do not use or store equipment outdoors.
- 3. Locate and familiarize yourself with all warning decals on the home gym.
- 4. Replace damaged or worn upholstery immediately.

REGISTER WARRANTY ONLINE

To register your product for warranty, visit **puretecfitness.com**

BEFORE YOU BEGIN

Thank you for selecting the Inspire Fitness FLB2C. Service of your bench should only be performed by an authorized Inspire retailer. Service performed by anyone else can result in loss of warranty. For your safety and benefit, read this manual carefully before using the machine. As a manufacturer, we are committed to providing you complete customer satisfaction. If you have any questions, or find there are missing or damaged parts, please call our TOLL-FREE customer service number. Our Customer Service agents will provide immediate assistance to you.




Email


service@puretecfitness.com



This bench is for adult use only. Do not let children play with the bench. Use caution while adjusting or working out on the bench.



Pull spring to unfold or fold leg. Make sure hands are clear of pivot area. Make sire spring pin is fully engaged in locking holes after each adjustment.



Swivel lock lever under pad to release back pad. Raise the head end of the pad so the free end of the suport tube slips into a slot for a desired position. Before use, make sure the support tube is secure in a slot.

When folding the bench flat, keep hands clear of any pivot areas or closing areas. make sure the lock lever is locked over catch pin before moving.





WARRANTY

This Warranty applies to Inspire Strength products manufactured or distributed by Pure-tec Limited.

LIMITED LIFETIME FRAME: Includes Frame and Welds	LIMITED LIFETIME PARTS: Includes Upholstery, Hardware, etc	LIMITED LIFETIME MOVING PARTS: Includes Pulleys, Cables, etc
---	---	---

PLEASE NOTE THIS INSPIRE PRODUCT IS NOT MADE FOR COMMERCIAL USE

Using a non-commercial product in a commercial setting can result in serious injury or death.

Pure-Tec Limited warrants that the Product you have purchased for light-commercial, personal, family or household use from Pure-Tec Limited or from an authorized Pure-Tec Limited reseller is free from defects in materials or workmanship under normal use during the warranty period. Your sales receipt, showing the date of purchase of the Product, is your proof of the date of purchase. This warranty extends only to you, the original purchaser. It is not transferable to anyone who subsequently purchases the Product from you. It excludes expendable parts such as paint and finish. This Warranty becomes VALID ONLY if the Product is assembled / installed according to the instructions / directions included with the Product.

Replacement and repair of parts

During the warranty period Pure-Tec Limited will, at no additional charge, repair or replace the Product if it becomes defective, malfunctions, or otherwise fails to conform with this Warranty under normal light-commercial, personal, family, or household use. In repairing the product Pure-Tec Limited may replace defective parts with, at the option of Pure-Tec Limited, serviceable used parts that are equivalent to new parts in performance, or new parts. All exchanged parts and Products replaced under this warranty will become the property of Pure-Tec Limited. Pure-Tec Limited reserves the right to change manufacturers and or specification of any part to cover any existing warranty.

Service procedures

To obtain warranty parts, you must return the parts to Pure-Tec Limited or an authorized Pure-Tec Limited retailer in its original container (or equivalent). You must pre-pay any shipping charges, taxes, or any other charges associated with transportation of the Product. In addition, you are responsible for insuring any Product shipped or returned. You assume the risk of loss during shipment. You must present Pure-Tec Limited with proof-of-purchase documents (including the date of purchase, Model, and Serial Number). Any evidence of alteration, erasing or forgery of proof -of-purchase documents will be cause to void this Warranty. Register your warranty online visit www. puretecfitness.com

Conditions and Exceptions

This Warranty does not extend to any Product not purchased from Pure-Tec Limited or from unauthorised Pure-Tec Limited reseller. This Warranty does not extend to any Product that has been damaged or rendered defective; (a) as a result of accident, misuse, or abuse; (b) by the use of parts not manufactured or sold by Pure-Tec Limited; (c) by modification of the Product; (d) as a result of service by anyone other than Pure-Tec Limited, or an authorized Pure-Tec Limited warranty service provider; (e) product that has not been properly maintained (follow maintenance schedule found on product). Should any product submitted for Warranty service be found to be ineligible, an estimate of repair cost will be furnished and the repair will be made if requested by you upon Pure-Tec Limited receipt of payment or acceptable arrangement of payment.

Disclaimer

EXCEPT AS EXPRESSLY SET FORTH IN THIS WARRANTY PURE-TEC LIMITED MAKES NO OTHER WARRANTIES; EXPRESSED OR IMPLIED INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. PURE-TEC LTD EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS WARRANTY. NEITHER PURE-TEC LIMITED NOR ANY OF ITS AFFILIATES SHALL BE RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. PURE-TEC LIMITED IS NOT RESPOSIBLE FOR THE REPAIR OR REPLACEMENT OF ANY PARTS THAT PURE-TEC LIMITED DETERMINES HAVE BEEN SUBJECTED AFTER THE DATE OF MANUFACTURE TO ALTERATION, NEGLECT, ABUSE, MISUSE, NORMAL WEAR & TEAR, ACCIDENT, DAMAGE DURING TRANSIT OR INSTALLATION, FIRE, FLOOD, OR ANY ACT OF GOD. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU. This Warranty gives you specific legal rights and you may also have other rights that may vary from state to state. This is the only express warranty applicable to Pure-Tec Ltd's "Inspire" branded strength products. Pure-Tec Ltd's "Inspire" branded strength products. Pure-Tec Limited neither assumes nor authorizes anyone to assume for it any other express warranty.

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



Distributed by:

Pure-Tec Limited www.puretecfitness.com service@puretecfitness.com

Pg. 20 V1.0



www.puretecfitness.com