

# 4.27 m (14 ft) OCTAGON GAZEBO

Installation and Operating Instructions – YM12721



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


Revised 12-1-2022

## YARDISTRY®

Yardistry – North America  
Toll Free Customer Support:  
1.888.509.4382

info@yardistrystructures.com  
www.yardistrystructures.com

Regular Hours: Mon - Fri, 8:30 am - 5:00  
pm EST (excl. holidays)  
(For extended hours see our website)  
English and French Spoken



Height: 10' 5-5/8" (3.192 m)

## **Important Safety Notice!**

Yardistry components are intended for privacy, decorative and ornamental use only.

### **Product is NOT INTENDED for the following:**

- A safety barrier to prevent unsupervised access to pools, hot tubs, spas or ponds.
- As load bearing support for a building, structure, heavy objects or swings.
- Used in structures that trap wind, rain or snow that would create extra load on the product.

### **Accumulated snow must be removed from roof.**

**DO NOT** climb or walk on roof for any reason.

**Permanent structures may require a building permit.** As the purchaser and or installer of this product you are advised to consult local planning, zoning and building inspection departments for guidance on applicable building codes and/or zoning requirements.

**Wood is NOT flame retardant and will burn.** Grills, fire pits and chimineas are a fire hazard if placed too close to a Yardistry structure. Consult user's manual of the grill, fire pit or chimenea for safe distances from combustible materials.

**Wear gloves to avoid injury** from possible sharp edges of individual elements before assembly.

**During installation, follow all safety warnings provided with your tools and use OSHA approved safety glasses.** Some structures may require two or more people to install safely.

**Check for underground utilities before digging or driving stakes into the ground!**

**It is important during assembly to closely follow the instructions,** complete the assembly on a solid level surface and that you follow the instruction to square up, level and anchor the structure, this will reduce the gap at wood connections during assembly.

## **General Information**

**General Information:** Wood components are manufactured with Cedar (C. Lanceolata) which is protected with factory applied water-based stain. Knots, small checks (cracks) and weathering are naturally occurring and do not affect the strength of the product. Annual application of a water-based water repellent sealant or stain is important and will help reduce weathering and checks.

**[www.yardistrystructures.com](http://www.yardistrystructures.com)**

Questions?

Call toll free or write us at:

1 (888) 509-4382

[info@yardistrystructures.com](mailto:info@yardistrystructures.com)

Regular Hours: Mon - Fri, 8:30 am - 5:00 pm EST  
(excl. holidays)

(For extended hours see our website)

English and French Spoken

Patents Pending

# Limited Warranty

Yardistry warrants that this product is free from defect in materials and workmanship for a period of one (1) year from the original date of purchase. In addition, for any product with lumber, all lumber is warranted for five (5) years against rot and decay. This warranty applies to the original owner and registrant and is non-transferable.

Regular maintenance is required to assure the integrity of your product and is a requirement of the warranty. This warranty does not cover any inspection costs.

**This Limited Warranty does not cover:**

- Labour for replacement of any defective item(s);
- Incidental or consequential damages;
- Cosmetic defects which do not affect performance or integrity;
- Vandalism; improper use or installation; acts of nature, including but not limited to wind, storms, hail, floods, excessive water exposure;
- Minor twisting, warping, checking or any other natural occurring properties of wood that do not affect performance or integrity.

Yardistry products have been designed for safety and quality. Any modifications made to the original product could damage the structural integrity of the product leading to failure and possible injury. Yardistry cannot assume any responsibility for modified products. Furthermore, modification voids any and all warranties.

**This product is warranted for RESIDENTIAL USE ONLY. Yardistry disclaims all other representations and warranties of any kind, express or implied.**

*This Warranty gives you specific legal rights. You may have other rights as well which vary from state to state or province to province. This warranty excludes all consequential damages, however, some states/provinces do not allow the limitation or exclusion of consequential damages, and therefore this limitation may not apply to you.*

# Instructions for Proper Maintenance

Your Yardistry structure is designed and constructed of quality materials. As with all outdoor products it will weather and wear. To maximize the enjoyment, safety and life of your structure it is important that you, the owner, properly maintain it.

## HARDWARE:

- Check metal parts for rust. If found, sand and repaint using a non-lead paint complying with 16 CFR 1303.
- Inspect and tighten all hardware after completion of assembly; after first month of use; and then annually. Do not over-tighten as to cause crushing and splintering of wood.
- Check for sharp edges or protruding screw threads, add washers if required.

## WOOD PARTS:

- Applying a water repellent or stain (water-based) on a yearly basis is important maintenance to maintain maximum life and performance of the product.
- Check all wood members for deterioration, structural damage and splintering. Sand down splinters and replace deteriorated wood members. As with all wood, some checking and small cracks in grain is normal
- Some gapping may occur at some wood connections.

## Assembly Guides

### Tools Required:

- |                              |                  |                      |
|------------------------------|------------------|----------------------|
| • Tape Measure               | • 8' Step Ladder | • 6' Step Ladder x 2 |
| • Carpenters Level           | • Safety Glasses | • Square             |
| • Standard or Cordless Drill | • Adult Helper   | • Ratchet            |
| • 7/16", 1/2" Wrench         | • Safety Gloves  |                      |
| • 7/16", 1/2" Socket         | • Hard Hat       |                      |

### Symbols:

Throughout these instructions symbols are provided in the top, right-hand corner of the page.




- Use Help, where this is shown, 2, 3 or 4 people are required to safely complete this step. To avoid injury or damage to the assembly make sure to get some help.



- Use a measuring tape to assure proper location.



- Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.



- Check that assembly is square before tightening bolts.

**If you dispose of your Yardistry structure:** Please disassemble and dispose of your unit so that it does not create any unreasonable hazards at the time it is discarded. Be sure to follow your local waste ordinances.

## Assembly Tips

Following are some helpful tips to make the assembly process smooth and efficient.

### PRE-ASSEMBLIES:

(i.e. Post and Beam Assemblies, Roof Rafter Assembly, etc)

- Work on a raised, solid and flat surface such as, a table or saw horse.
- Keep all connections flush where shown in the instructions.
- When assembling the beams keep parts flat, straight and snug when connecting.

### METAL PARTS:

- Roofing material may have sharp edges, wear safety gloves.
- Remove all plastic covering, on both sides of the metal panels, directly before installing each piece.
- Place roofing material on a non-abrasive surface before and after assembly as it can bend, dent and scratch easily.
- The roofing screws can easily crush the roof panels and roof edges when using a power drill. We recommend hand tightening the roofing screws so they sit snug and tight to the roofing material.

# Permanent Installation Examples

**Note: It is critically important you start with square, solid and level footings, concrete pad or deck to attach your structure.**

We supply Post Mounts with this structure which gives you the flexibility to permanently install your structure to a pre-existing or new wood or concrete surface.



- The hardware to attach the Post Mount to the structure is included.
- The hardware to mount the structure permanently will need to be purchased separately at your local hardware store.

If you are mounting to concrete footers see below for the correct locations and placement. Please double check for possibility of any underground utilities such as gas, telephone, cable or sprinkler lines.

Following are some examples of how to mount the structure to wood or concrete surfaces.

Refer to your local building and city codes, ordinances, neighbourhood covenants, or height restrictions regarding this type of structure for guidance on acceptable installation requirements.

## Concrete Footer




## Layout Dimensions for Octagon Gazebo




<b>A</b>	13' 3-5/8" (4.054 m)
<b>B</b>	5 6-1/8" (1.679 m)
<b>C</b>	3' 10-3/4" (1.188 m)
<b>D</b>	14' 4-3/4" (4.389 m)

## Permanent Installation Examples cont.

**Concrete Patio [min. 4.361 m x 4.361 m (14'3-5/8" x 14' 3-5/8"')] with 15.24 cm (6") clearance on all sides**



**Wood Deck [min. 4.361 m x 4.361 m (14'3-5/8" x 14' 3-5/8"')] with 15.24 cm (6") clearance on all sides**




Anchoring Hardware (not included)


*Post Mounts have a 1/2" diameter hole for anchoring hardware.*

**Part Identification** ( Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger. )


**1pc. (1061)** - Post Right 2184.4mm (86") FSC Y70229-1061



**1pc. (1059)** - Post Left 2184.4mm (86") FSC Y70229-1059




**6pc. (1056)** - Post Main 2184.4mm (86") FSC Y70229-1056




**8pc. (1577)** - Beam 1711mm (67-3/8") FSC Y50229-1577



**7pc. (1581)** - Rail Top 1567mm (61-11/16") FSC Y50229-1581




**7pc. (1582)** - Rail Bot 1567mm (61-11/16") FSC Y50229-1582




**98pc. (1066)** - Spindle 747.8mm (29-7/16") FSC Y50229-1066



**7pc. (1583)** - Filler Insert 1567mm (61-11/16") FSC Y50229-1583



**8pc. (1588)** - Gusset Left 610mm (24") FSC




**8pc. (1589)** - Gusset Right 610mm (24") FSC




# Part Identification ( Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger. )

**8pc. (1579)** - Rafter Corner LT 2415.5mm (95-1/8") FSC Y50229-1579



**8pc. (1580)** - Rafter Corner RT 2415.5mm (95-1/8") FSC Y50229-1580




**8pc. (1578)** - Rafter Centre 2263.4mm (89-1/8") FSC Y50229-1578




**8pc. (1585)** - Strap Top 562.2mm (22-1/8") FSC




**8pc. (1587)** - Strap Mid 966.6mm (38-1/16") FSC Y50229-1587




**8pc. (1586)** - Strap Bot 1370.9mm (54") FSC Y50229-1586




**8pc. (1584)** - Fascia 1750.4mm (68-15/16") FSC Y50229-1584



# Hardware Identification ( Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger. )





8pc. Roof Edge - (Y01037-652)




16pc. Ridge Clip - (Y01037-653)



8pc. Ridge Cap - (Y01037-654)




1pc. - Gazebo ID Plaque (Y70800-104)




1pc. - Post to Roof Tie Bracket Set (8Pk) (Y70829-353)

1pc. - Ridge Clip Weather Seal (16Pk) (Y70818-655)




1pc. - 135° Angle Bracket Set (8Pk) (Y70818-389)

1pc. Peak Cap (Y01030-351)




1pc. - Post Mount Set (8Pk) (Y70829-355)



1pc. - Rafter/Beam Bracket Set (8Pk) (Y70829-281)



1pc. - Peak Post (Y01000-094)



1pc. - Corner Cap Set (8Pk) (Y70830-354)

1pc. Carriage Bolt (Y07490-260)



1pc. Contour Washer (Y05918-211)



1pc. Spring Clip (Y09490-001)



1pc. Base Plate (Y01029-352)

1pc. 1/4" Nut (Y08490-200)














1pc. - Octagon Roof Peak Set (Y70829-390)

1pc. Peak Loop (Y20018-003)




# Hardware Identification ( Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger. )




32pc. 5/16" Lock Washer (Y05318-300)




56pc. - 1/4" Lock Nut (Y08318-203)




1pc. #2 x 2" Robertson Driver (Y00400-005)



160pc. 1/4-5/16 x 1-1/4" Large Washer (Y05118-311)




1pc. - Hex Driver (Y00400-004)



32pc. 5/16 - T-Nut (Y08518-300)

# Step 1: Inventory Parts - Read This Before Starting Assembly



- A.** This is the time for you to inventory all your hardware, wood and accessories, referencing the parts identification sheets. This will assist you with your assembly.
- Each step indicates which bolts and/or screws you will need for assembly, as well as any flat washers, lock washers, t-nuts or lock nuts.
- B.** If there are any missing or damaged pieces or you need assistance with assembly please contact the consumer relations department directly. Call us before going back to the store.

**1-888-509-4382**

**support@yardistrystructures.com**

- C.** Read the assembly manual completely, paying special attention to ANSI warnings; notes; and safety/maintenance information on pages 1 - 4.
- Follow the instructions in order.
  - This structure is designed to be assembled and installed ideally by four people, DO NOT attempt to install alone.
  - Consider the slope of elevation where you plan to install the structure. Also, check for gas, telephone, other utilities or sprinkler line locations prior to excavating any holes.
- D.** Before you discard your cartons fill out the form below.
- The carton I.D. stamp is located on the end of each carton.
  - Please retain this information for future reference. You will need this information if you contact the Consumer Relations Department.

**PRODUCT NUMBER: YM12721**

CARTON I.D. STAMP: \_\_ \_\_ \_\_ \_\_ \_\_ 1 4 4 5 9 \_\_ (Box 1)

CARTON I.D. STAMP: \_\_ \_\_ \_\_ \_\_ \_\_ 1 4 4 5 9 \_\_ (Box 2)


CARTON I.D. STAMP: \_\_ \_\_ \_\_ \_\_ \_\_ 1 4 4 5 9 \_\_ (Box 3)

# Step 2: Rail Assemblies

## Part 1

**A:** Arrange 14 (1066) Spindles evenly across two (1583) Filler Inserts (notches facing down) to set height. (F2.1)

**B:** On top of one end, place a (1583) Filler Insert. Place (1066) Spindles into slots to set spacing. (F2.2 and F2.3)



### Wood Parts


7 x (1583) Filler Insert

98 x (1066) Spindle

## Step 2: Rail Assemblies Part 2

**C:** Place (1582) Rail Bot against bottom of spindles, flush to the outside edges of the end spindles. Centre spindles over holes in (1582) Rail Bot. Attach with one #8 x 3" Wood Screw per spindle. (F2.3 and F2.4)

**D:** Repeat Steps A - C six more times to create seven partial Rail Assemblies. Remove (1066) Filler Inserts when complete.



### Wood Parts


7 x (1582) Rail Bot

### Hardware

98 x #8 x 3" Wood Screw

## Step 2: Rail Assemblies Part 3

E: Place a (1583) Filler Insert at top of (1066) Spindles, flush to outside edges of end spindles and attach with one #8 x 2" Wood Screw per spindle. (F2.5 and F2.6)




**Hardware**  
98 x #8 x 2" Wood Screw

## Step 2: Rail Assemblies Part 4

**F:** On top of (1583) Filler Insert and flush to each end, place (1581) Rail Top. Attach (1583) Filler Insert to (1581) Rail Top with three #8 x 1-1/2" Wood Screws as shown in F2.7, F2.8 and F2.9.

**G:** Repeat Steps E - F six more times to create seven Rail Assemblies.



### Wood Parts

7 x (1581) Rail Top


### Hardware

21 x #8 x 1-1/2" Wood Screw

# Step 3: Post Assemblies

**A:** Flush to the bottom of one (1059) Post Left and one (1061) Post Right place one Post Mount tight to the inside of each post then attach with two #10 x 1-1/4" Pan Screws per Post Mount. (F3.1, F3.2, F3.3 and F3.4)

**B:** Flush to the bottom of each (1056) Post Main place one Post Mount tight to the inside of each post then attach with two #10 x 1-1/4" Pan Screws per Post Mount. There will be six Post Main Assemblies. (F3.5 and F3.6)



### Wood Parts

- 6 x (1056) Post Main
- 1 x (1059) Post Left
- 1 x (1061) Post Right

### Components

- 8 x Post Mount

### Hardware

- 16 x #10 x 1-1/4" Pan Screw


# Step 4: Attach Rail Assemblies to Posts Part 1



**A:** Place one (1056) Post Main on each side of one Rail Assembly. Rail Assembly should sit tight to top of post insert. See F4.1 and F4.2 for correct positioning of posts. At an angle attach (1581) Rail Top to posts with two #8 x 2-1/2" Wood Screws. (F4.1, F4.2, F4.3 and F4.4)

**B:** For each (1066) Spindle which is next to a post, at an angle, pre-drill with a 1/8" drill bit then attach (1066) Spindles to posts, on an angle, with two #8 x 3" Wood Screws per post. (F4.5 and F4.6)

**C:** Repeat Steps A and B for a second Rail and Post Assembly using two (1056) Post Mains.



## Hardware

4 x #8 x 2-1/2" Wood Screw

8 x #8 x 3" Wood Screw


# Step 4: Attach Rail Assemblies to Posts

## Part 2



**D:** Place one (1056) Post Main on one side of one Rail Assembly and (1059) Post Left on the other side. Rail Assembly should sit tight to top of post insert. See F4.7 and F4.8 for correct positioning of posts. At an angle, attach (1581) Rail Top to posts with two #8 x 2-1/2" Wood Screws. (F4.7, F4.8, F4.9 and F4.10)

**E:** For each (1066) Spindle which is next to a post, at an angle, pre-drill with a 1/8" drill bit then attach (1066) Spindles to posts, on an angle, with two #8 x 3" Wood Screws per post. (F4.11 and F4.12)



### Hardware

2 x #8 x 2-1/2" Wood Screw


4 x #8 x 3" Wood Screw

# Step 4: Attach Rail Assemblies to Posts

## Part 3




F: Repeat Steps D and E using one (1056) Post Main with one (1061) Post Right. See F4.13 and F4.14 for correct positioning of Posts. (F4.13, F4.14, F4.15, F4.16, F4.17 and F4.18)



### Hardware

- 2 x #8 x 2-1/2" Wood Screw
- 4 x #8 x 3" Wood Screw


# Step 5: Main Wall Assembly



**A:** On one Rail/Post Main Assembly place one (1577) Beam against the wide side of the posts, flush to the edges then loosely attach with two 1/4 x 5" Hex Bolts (with 1/4-5/16" large washer, 135° Bracket and 1/4" lock nut) in the bottom holes. Make sure assembly is square then attach (1577) Beam to posts with two #8 x 3" Wood Screws in the top holes. Tighten bolts. (F5.1 and F5.2)

**B:** Place one (1588) Gusset Left and one (1589) Gusset Right tight to the Posts and bottom of (1577) Beam then attach to beam with two 5/16 x 2-1/4" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) per gusset. Pre-drill with a 1/8" drill bit then attach gusset to posts with two 1/4 x 1-15/16" Lag Screws (with 1/4-5/16" large washer) per gusset. (F5.1 and F5.3)

**C:** Repeat Steps A and B for the second Rail/Post Main Assembly. This makes two Main Wall Assemblies.




## Wood Parts

- 2 x (1577) Beam
- 2 x (1588) Gusset Left
- 2 x (1589) Gusset Right

## Hardware

- 4 x 1/4 x 5" Hex Bolt (1/4-5/16" large washer, 135° Bracket, 1/4" lock nut)
- 8 x 5/16 x 2-1/4" Hex Bolt (5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)
- 8 x 1/4 x 1-15/16" Lag Screw (1/4-5/16" large washer)
- 4 x #8 x 3" Wood Screw


# Step 6: Left and Right Wall Assemblies



**A:** On one Rail/Post Left Assembly place one (1577) Beam against the wide side of the posts, flush to the edges then loosely attach with two 1/4 x 5" Hex Bolts (with 1/4-5/16" large washer, 135° Bracket and 1/4" lock nut) in the bottom holes. Make sure assembly is square then attach (1577) Beam to posts with two #8 x 3" Wood Screws in the top holes. Tighten bolts. (F6.1 and F6.2)

**B:** Place one (1588) Gusset Left and one (1589) Gusset Right tight to the Posts and bottom of (1577) Beam then attach to beam with two 5/16 x 2-1/4" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) per gusset. Pre-drill with a 1/8" drill bit then attach gusset to posts with two 1/4 x 1-15/16" Lag Screws (with 1/4-5/16" large washer) per gusset. (F6.1 and F6.3)

**C:** Repeat Steps A and B for the Rail/Post Right Assembly.





### Wood Parts

- 2 x (1577) Beam
- 2 x (1588) Gusset Left
- 2 x (1589) Gusset Right

### Hardware

- 4 x 1/4 x 5" Hex Bolt (1/4-5/16" large washer, 135° Bracket, 1/4" lock nut)
- 8 x 5/16 x 2-1/4" Hex Bolt (5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)
- 8 x 1/4 x 1-15/16" Lag Screw (1/4-5/16" large washer)
- 4 x #8 x 3" Wood Screw


# Step 7: Frame Assembly Part 1



**A:** Move Wall Assemblies to the final location. Make sure the ground is flat and level before continuing assembly.

**B:** With one person holding the Left Wall Assembly and one person holding the Right Wall Assembly place one (1577) Beam in between walls so it is flush to the top of previously installed (1577) Beams. Loosely attach (1577) Beam to walls with two 1/4 x 5" Hex Bolts (with 1/4-5/16" large washer and 1/4" lock nut) in the bottom holes. Bolt goes through 135° Brackets previously installed. Make sure assembly is square then attach (1577) Beam to walls with two #8 x 3" Wood Screws in the top holes. Tighten bolts. (F7.1, F7.2 and F7.3)

**C:** Place one (1588) Gusset Left and one (1589) Gusset Right tight to the Posts and bottom of (1577) Beam then attach to beam with two 5/16 x 2-1/4" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) per gusset. Pre-drill with a 1/8" drill bit then attach gusset to posts with two 1/4 x 1-15/16" Lag Screws (with 1/4-5/16" large washer) per gusset. (F7.1 and F7.2)




## Wood Parts

- 1 x (1577) Beam
- 1 x (1588) Gusset Left
- 1 x (1589) Gusset Right

## Hardware






- 2 x 1/4 x 5" Hex Bolt (1/4-5/16" large washer, 1/4" lock nut)
- 4 x 5/16 x 2-1/4" Hex Bolt (5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)
- 4 x 1/4 x 1-15/16" Lag Screw (1/4-5/16" large washer)
- 2 x #8 x 3" Wood Screw

# Step 7: Frame Assembly Part 2



**D:** Place one Rail Assembly between Left Wall Assembly and one Main Wall Assembly. Rail Assembly should sit tight to top of post inserts. At an angle, attach (1581) Rail Top to posts with two #8 x 2-1/2" Wood Screws. (F7.4, F7.5 and F7.6)

**E:** For each (1066) Spindle which is next to a post, at an angle, pre-drill with a 1/8" drill bit then attach (1066) Spindles to posts, on an angle, with two #8 x 3" Wood Screws per post. (F7.7 and F7.8)




### Hardware

4 x #8 x 2-1/2" Wood Screw

8 x #8 x 3" Wood Screw

# Step 7: Frame Assembly Part 3





**F:** Place one (1577) Beam in between walls so it is flush to the top of previously installed (1577) Beams. Loosely attach (1577) Beam to walls with two 1/4 x 5" Hex Bolts (with 1/4-5/16" large washer and 1/4" lock nut) in the bottom holes. Bolt goes through 135° Brackets previously installed. Make sure assembly is square then attach (1577) Beam to walls with two #8 x 3" Wood Screws in the top holes. Tighten bolts. (F7.9, F7.10 and F7.11)


**G:** Place one (1588) Gusset Left and one (1589) Gusset Right tight to the Posts and bottom of (1577) Beam then attach to beam with two 5/16 x 2-1/4" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) per gusset. Pre-drill with a 1/8" drill bit then attach gusset to posts with two 1/4 x 1-15/16" Lag Screws (with 1/4-5/16" large washer) per gusset. (F7.9 and F7.10)

**H:** Repeat Steps D - G for another Rail Assembly and Wall Assembly next to the first set. (F7.12)


**F7.9**



**F7.11**  
*Inside View*



**F7.12**




**Wood Parts**

- 2 x (1577) Beam
- 2 x (1588) Gusset Left
- 2 x (1589) Gusset Right

**Hardware**

- 4 x 1/4 x 5" Hex Bolt (1/4-5/16" large washer, 1/4" lock nut)
- 8 x 5/16 x 2-1/4" Hex Bolt (5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)
- 8 x 1/4 x 1-15/16" Lag Screw (1/4-5/16" large washer)
- 4 x #8 x 3" Wood Screw


# Step 7: Frame Assembly Part 4




**I:** Place remaining Rail Assembly between Right Wall Assembly and Main Wall Assembly. Rail Assembly should sit tight to top of post inserts. At an angle, attach (1581) Rail Top to posts with two #8 x 2-1/2" Wood Screws. (F7.13, F7.14 and F7.15)

**J:** For each (1066) Spindle which is next to a post, at an angle, pre-drill with a 1/8" drill bit then attach (1066) Spindles to posts, on an angle, with two #8 x 3" Wood Screws per post. (F7.13 and F7.16)


**F7.13**




**F7.14**



**F7.15**



**F7.16**




**Hardware**

- 2 x #8 x 2-1/2" Wood Screw
- 4 x #8 x 3" Wood Screw

# Step 7: Frame Assembly


## Part 5




**K:** Place one (1577) Beam in between walls so it is flush to the top of previously installed (1577) Beams. Loosely attach (1577) Beam to walls with two 1/4 x 5" Hex Bolts (with 1/4-5/16" large washer and 1/4" lock nut) in the bottom holes. Bolt goes through 135° Brackets previously installed. Make sure assembly is square then attach (1577) Beam to walls with two #8 x 3" Wood Screws in the top holes. Tighten bolts. (F7.17, F7.18 and F7.19)

**L:** Place one (1588) Gusset Left and one (1589) Gusset Right tight to the Posts and bottom of (1577) Beam then attach to beam with two 5/16 x 2-1/4" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) per gusset. Pre-drill with a 1/8" drill bit then attach gusset to posts with two 1/4 x 1-15/16" Lag Screws (with 1/4-5/16" large washer) per gusset. (F7.17 and F7.18)


**F7.17**



**F7.19**  
Inside View



**F7.18**  
Outside View



### Wood Parts

- 1 x (1577) Beam
- 1 x (1588) Gusset Left
- 1 x (1589) Gusset Right

### Hardware


- 2 x 1/4 x 5" Hex Bolt (1/4-5/16" large washer, 1/4" lock nut)
- 4 x 5/16 x 2-1/4" Hex Bolt (5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)
- 4 x 1/4 x 1-15/16" Lag Screw (1/4-5/16" large washer)
- 2 x #8 x 3" Wood Screw

# Step 7: Frame Assembly


## Part 6



**M:** In the places shown in F7.20, measure 2-1/2" (6.4 cm) down from the top of the Post then attach Post Roof Tie Brackets to Posts with two #10 x 1-1/4" Pan Screws per bracket. (F7.20 and F7.21)



F7.20



F7.21

### Components

8 x Post Roof Tie Bracket

### Hardware

16 x #10 x 1-1/4" Pan Screw

# Step 8: Anchoring Frame Assembly




**A:** Make sure the distance between the entrance posts are the same at the top and bottom of the assembly. (F8.1)

**B:** Make sure each corner is square and level. The diagonal distance between the hole in the Post Mount of two opposite Post Assemblies should be  $164\frac{1}{8}$ " (4.167 m). (F8.1)


**C:** Depending on what you are placing the Gazebo on will determine how you anchor it to that surface. Please refer to pages 6 and 7 for installation examples.

***Any hardware or extra materials for mounting will have to be purchased in advance.***



# Step 9: Roof Panel Frame Part 1

**A:** On each side of one (1578) Rafter Centre place one (1579) Rafter Corner LT and one (1580) Rafter Corner RT so the tops are flush. Attach through (1579) Rafter Corner LT and (1580) Rafter Corner RT with two #8 x 1-1/2" Wood Screws per side. (F9.1 and F9.2)



## Wood Parts


8 x (1579) Rafter Corner LT  
 8 x (1580) Rafter Corner RT  
 8 x (1578) Rafter Centre

## Hardware

32 x #8 x 1-1/2" Wood Screw

# Step 9: Roof Panel Frame Part 2

**B:** Place one (1584) Fascia on the bottom of (1578) Rafter Centre, (1579) Rafter Corner LT and (1580) Rafter Corner RT, flush to the outside Corner Rafters and tops of all three rafters. Attach with six #8 x 2-1/2" Wood Screws. (F9.3 and F9.4)



### Wood Parts

8 x (1584) Fascia


### Hardware

48 x #8 x 2-1/2" Wood Screw

# Step 9: Roof Panel Frame Part 3

**C:** Place one (1585) Strap Top, one (1587) Strap Mid, and one (1586) Strap Bot in the grooves of the rafters so the outside edges are flush with the outside rafters then attach with six #8 x 1-1/2" Wood Screws per board. (F9.5 and F9.6)

**D:** Repeat Steps A - C seven more times to create eight Roof Panel Frames.



### Wood Parts

- 8 x (1585) Strap Top
- 8 x (1587) Strap Mid
- 8 x (1586) Strap Bot


### Hardware

- 144 x #8 x 1-1/2" Wood Screw


## Step 10: Attach Rafter Beam Brackets

**A:** On the back of seven Roof Panel Frames place one Rafter Beam Bracket on each (1578) Rafter Centre then loosely attach each bracket to rafters with one 1/4 x 2" Hex Bolt (with two 1/4-5/16" large washers and one 1/4" lock nut). (F10.1 and F10.2)

**F10.1**  
Top View



**F10.2**  
Back View





### Components:

7 x Rafter Beam Bracket

### Hardware

7 x 1/4 x 2" Hex Bolt  
(1/4-5/16" large washer x 2, 1/4" lock nut)



# INSTALLING ROOFING MATERIAL

---


## CAUTION!

Roofing material may have sharp edges! Wear gloves!




## HANDLE WITH CARE!

Place roofing material on a non-abrasive surface before assembly as it can bend, dent and scratch easily.

**WARNING – DO NOT OVER TIGHTEN ROOFING SCREWS!  
Over tightening screws will cause roofing material to crush.**



The roofing screws can easily crush the Roof Panels and Roof Edges when using a power drill. We recommend hand tightening the roofing screws so that they sit snug and tight to the roofing material.





# INSTALLING ROOFING MATERIAL

---

## CAUTION!

Roofing material may have sharp edges! Wear gloves!

**BE SURE TO REMOVE ALL PLASTIC COVERING, ON BOTH SIDES OF THE ALUMINUM PANELS AND TRIM, DIRECTLY BEFORE INSTALLING EACH PIECE. *(One side is clear and the other is blue, both must be removed.)***



# Step 11: Attach Roof Panels


**Note:** Be sure to remove all plastic covering on both sides of the metal panels directly before installing each piece.

**A:** On one Roof Panel Frame place one LT Panel flush to the top and side of (1579) Rafter Corner LT. There will be a slight overhang at the bottom. (F11.1, F11.2 and F11.3)

**B:** Place one RT Panel beside LT Panel so the panels overlap and screw holes line up. RT Panel to be flush to side of (1580) Rafter Corner RT and top of Roof Panel Frame. (F11.1, F11.2, F11.3 and F11.4)

**C:** Attach Roof Panels to Roof Panel Frame using 24 #8 x 1" Hex Roofing Screws in locations shown in F11.1. Do not install screws to the bottom. Be sure not to overtighten screws.

**D:** Repeat Steps A - C for each Roof Panel Frame.



**Roof Panel Set:**

- 8 x LT Panel
- 8 x RT Panel

**Hardware**


- 192 x #8 x 1" Hex Roofing Screw

## Step 12: Attach Roof Edge


**A:** Place one Roof Edge on the bottom of Roof Panel Frame. Attach Roof Edge with nine #8 x 1" Roofing Screws. (F12.1, F12.2 and F12.3)

**B:** Repeat Step A for each Roof Panel Frame.


F12.1



**DO NOT** overtighten screws, could cause damage to roofing material



F12.2



F12.3

**Components:**

8 x Roof Edge

**Hardware**



72 x #8 x 1" Roofing Screw

# Step 13: Attach Ridge Clips



**A:** Place Weather Seal on the inside of two Ridge Clips then place one Ridge Clip 1" (2.54 cm) from the top and 2-1/2" (6.35 cm) up from the bottom of (1579) Rafter Corner LT and (1580) Rafter Corner RT as per F13.4, make sure not to compress Weather Seal. Attach with six #7 x 3/4" Wood Screws per Ridge Clip. Ridge Clips must cover the Roof Panels. (F13.1, F13.2, F13.3 and F13.4)

**B:** Repeat Step A for each Roof Panel Frame.




**Components**

- 16 x Ridge Clip
- 16 x Weather Seal

**Hardware**

- 96 x #7 x 3/4" Wood Screw


# Step 14: Attach Roof Panels to Frame Part 1



**A:** Starting to the right of the opening in the frame assembly, with four assemblers lift two Roof Panel Frames with Rafter Beam Brackets up and over frame assembly taking care not to drag roof panels on beams. **One assembler must remain on a ladder to hold Roof Panel Frames in place until secured.** (F14.1 and F14.2)

**B:** Starting at the bottom and working up, loosely connect Roof Panel Frames through the Corner Rafters with four 1/4 x 2-3/4" Hex Bolts (with two 1/4-5/16" large washers and one 1/4" lock nut). To align bolt holes helper in the centre may have to push up the centre of the panels while other helpers make sure corners are aligned. (F14.3 and 14.4)


**C:** Attach three more Roof Panel Frames as done in Steps A and B.






### Hardware

16 x 1/4 x 2-3/4" Hex Bolt  
(1/4-5/16" large washer x 2, 1/4" lock nut)

# Step 14: Attach Roof Panels to Frame Part 2



**D:** Attach two Roof Panel Frames with Rafter Beam Brackets up and over frame assembly, taking care not to drag roof panels on beams, and attach with four 1/4 x 2-3/4" Hex Bolts (with two 1/4-5/16" large washers and one 1/4" lock nut) per connecting rafters. To align bolt holes helper in the centre may have to push up the centre of the panels while other helpers make sure corners are aligned. (F14.5, F14.6, F14.7 and F14.8)




### Hardware

8 x 1/4 x 2-3/4" Hex Bolt  
(1/4-5/16" large washer x 2, 1/4" lock nut)

## Step 15: Roof Cap Assembly

**A:** Insert one Carriage Bolt with Contoured Washer through the top of Peak Cap, into Peak Post. Attach Spring Clip to Carriage Bolt. The Spring Clip holds the assembly together. (F15.1)

**B:** Insert one 1/4" Nut into the Peak Loop then insert Carriage Bolt into Peak Base Plate and attach Peak Loop to Carriage Bolt. Be careful nut is loose and will fall out until attached to Carriage Bolt. (F15.1)



### Components:




1 x Carriage Bolt	1 x Peak Loop
1 x Contoured Washer	1 x Spring Clip
1 x Peak Cap	1 x 1/4" Nut
1 x Peak Post	
1 x Peak Base Plate	

# Step 16: Attach Roof Cap and Final Roof Panel



**A:** Place Roof Cap Assembly in gap at the top of the Roof Panels. Peak Cap to be lined up with Corner Rafters. (F16.1 and F16.2)

**B:** Lift last Roof Panel Frame (without Rafter Beam Brackets) over assembly taking care not to drag the panel on the beams. Panel fits under the Peak Cap, push up on Peak Loop to lift Peak Cap Assembly. The centre of the other panels may have to be pushed up to fit last panel. Starting at the bottom and working up loosely connect Roof Panels through the Corner Rafters with four 1/4 x 2-3/4" Hex Bolts (with two 1/4-5/16" large washers and one 1/4" lock nut) per side. (F16.1, F16.3 and F16.4)




*Start at bottom and work up the rafters*

### Hardware

8 x 1/4 x 2-3/4" Hex Bolt  
(1/4-5/16" large washer x 2, 1/4" lock nut)



# Step 17: Tighten Rafter Bolts



**A:** Follow the sequence in F17.1 to tighten the bottom bolts. While tightening bolts have a helper push up the centre of the roof. The helper on the outside of the frame makes sure corners are aligned. (F17.1)

**B:** Tighten remaining bolts, keeping Corner Rafter flush at the bottom.


**C:** Align Roof to Post Roof Tie Bracket and fasten to Corner Rafters with two #10 x 1-1/4" Pan Screws per bracket. (F17.2)



## Hardware



16 x #10 x 1-1/4" Pan Screw

# Step 18: Attach Rafter Beam Bracket



**A:** On the final Roof Panel Frame attach one Rafter Beam Bracket on (1578) Rafter Centre with one 1/4 x 2" Hex Bolt (with two 1/4-5/16" large washers and one 1/4" lock nut). (F18.1)

**B:** Attach each Rafter Beam Bracket to (1577) Beams and (1578) Rafter Centres with four #12 x 1-1/2" Pan Screws per bracket. (F18.2)




### Components:

1 x Rafter Beam Bracket

### Hardware


1 x 1/4 x 2" Hex Bolt  
(1/4-5/16" large washer x 2, 1/4" lock nut)  
32 x #12 x 1-1/2" Pan Screw

# Step 19: Attach Ridge Caps




**A:** Slide each Ridge Cap over the Ridge Clips, with cut edge leading, towards the centre of the roof until they are under the Peak Cap, lifting Peak Cap by pushing up the Peak Loop so Ridge Cap fit under Peak Cap. Attach each Ridge Cap using two #8 x 3/4" Sheet Metal Screws per Ridge Cap. (F19.1, F19.2 and F19.3)

**F19.1**




**F19.2**



#8 x 3/4" Sheet Metal Screw

**F19.3**



**Note:** To help Ridge Cap slide on easier use a lubricant such as liquid soap.

**Components:**

8 x Ridge Cap

**Hardware**


16 x #8 x 3/4" Sheet Metal Screw

## Step 20: Attach Corner Caps




**A:** At each corner place one Corner Cap tight to (1584) Fascia, push up so the bottom is tight to the bottom of the assemblies then attach with four #8 x 3/4" Sheet Metal Screws per Corner Cap. (F20.1 and F20.2)

F20.1



F20.2



### Components:

8 x Corner Cap


### Hardware

32 x #8 x 3/4" Sheet Metal Screw

# Step 21: Secure Peak Base Plate



**A:** Attach Peak Base Plate to (1578) Rafter Centres with eight #10 x 1-1/4" Pan Screws. To ensure Peak Base Plate is flat install screws in a criss-cross sequence. Screws may go in on an angle. (F21.1)



**Note:** Screws may go in on an angle


### Hardware

8 x #10 x 1-1/4" Pan Screw


## Step 22: Attach Plaque

**A:** Attach Yardistry Plaque to a prominent location on your Gazebo with two #10 x 1-1/4" Pan Screws. This provides warnings concerning safety and important contact information. A tracking number is provided to allow you to get critical information or order replacement parts for this specific model. (F22.1 and F22.2)

F22.1



F22.2



**Components:**

1 x Yardistry Plaque

**Hardware**

2 x #10 x 1-1/4" Pan Screw



Yardistry® 375 Sligo Road West, P.O. Box 10, Mount Forest, ON Canada N0G 2L1

Distributed by:  
Costco Wholesale Corporation  
P.O. Box 34535  
Seattle, WA 98124-1535  
USA  
1-800-774-2678  
www.costco.com

Costco Wholesale Canada Ltd.\*  
415 W. Hunt Club Road  
Ottawa, Ontario  
K2E 1C5, Canada  
1-800-463-3783  
www.costco.ca  
\* faisant affaire au Québec sous  
le nom les Entrepôts Costco

Importado por:  
Importadora Primex S.A. de C.V.  
Blvd. Magnocentro No. 4  
San Fernando La Herradura  
Huixquilucan, Estado de México  
C.P. 52765  
RFC: IPR-930907-S70  
(55)-5246-5500  
www.costco.com.mx

Costco Wholesale Australia Pty Ltd  
17-21 Parramatta Road  
Lidcombe NSW 2141  
Australia  
www.costco.com.au

Costco Wholesale UK Ltd /  
Costco Online UK Ltd  
Hartspring Lane  
Watford, Herts  
WD25 8JS  
United Kingdom  
01923 213113  
www.costco.co.uk

Costco Wholesale Spain S.L.U.  
Polígono Empresarial Los Gavilanes  
C/ Agustín de Betancourt, 17  
28906 Getafe (Madrid) España  
NIF: B86509460  
900 111 155  
www.costco.es

Costco Wholesale Iceland ehf.  
Kauptún 3-7, 210 Gardabaer  
Iceland  
www.costco.is

Costco France  
1 avenue de Bréhat  
91140 Villebon-sur-Yvette  
France  
01 80 45 01 10  
www.costco.fr

Costco Wholesale Japan Ltd.  
2 Kakuchi, 2 Gaiku, Kaneda-Nishi  
361 Urigura, Kisarazu shi  
Chiba, 292-0007 Japan  
0570-200-800  
www.costco.co.jp

Costco Wholesale Korea, Ltd.  
40, Ilijik-ro  
Gwangmyeong-si  
Gyeonggi-do, 14347, Korea  
1899-9900  
www.costco.co.kr

Costco Wholesale New Zealand Limited  
2 Gunton Drive  
Westgate  
Auckland 0814  
New Zealand  
www.costco.co.nz

Costco (China) Investment Co., Ltd.  
Room 1003, Block 2, 2388 Xiupu Road,  
Pudong New Area, Shanghai  
China 201315  
+86-21-6257-7065

Costco Wholesale Sweden AB  
Box 614  
114 11 Stockholm  
Sweden  
www.costco.se

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

AUSTRALIE : Nos articles sont offerts avec des garanties qui ne peuvent connaître d'exclusions au regard de la loi australienne sur la protection des consommateurs. Vous avez droit au remplacement ou au remboursement en cas de défaillance majeure de votre article ainsi qu'à une compensation en cas de perte ou de dommage prévisible. Vous avez aussi droit à la réparation ou au remplacement de l'article s'il n'est pas d'une qualité acceptable et que la défaillance n'est pas majeure.

AUSTRALIA: Nuestros productos cuentan con garantías que no se pueden excluir bajo las Leyes del Consumidor de Australia. Usted tiene derecho a un cambio o devolución en caso de un fallo importante ya una compensación por cualquier otra pérdida o daño razonablemente previsible. También tiene derecho a la reparación o reemplazo de los bienes, si éstos no cumplen con una calidad aceptable y el fallo no constituye un fallo importante.







## Customer Registration Card - Tarjeta de Registro del Cliente - Carte d'inscription du client

First Name - Primer Nombre - Prénom	Initial - Inicial - Initiale	Last Name - Apellido - Nom de famille

Street - Calle - Rue	PO Box - Casilla postal - Boîte postale	Apt. No. - App.

City - Ciudad - Ville	State/Province - Estado/Provincia - État/Province

ZIP/Postal Code - Código Postal - ZIP/Code postal	Country - País - Pays

E-mail Address - Dirección de E-mail - Adresse courriel	Telephone Number - No. de Teléfono - N° de téléphone

Model Name - Nombre del Modelo - Nom du modèle	Model Number (from front cover) - Número de Modelo (de la portada) - N° du modèle (page de couverture)

Date of Purchase - Fecha de Compra - Date d'achat (mm/dd/yyyy) (mm/dd/aaaa) (mm/jj/aaaa)	Place of Purchase - Comprado a - Lieu d'achat

Comments - Comentarios - Commentaires:

### Mail To - Enviar por Correo a - Envoyer par courrier à:

Yardistry  
375 Sligo Road West, PO Box 10  
Mount Forest, Ontario, Canada, N0G 2L0  
Attention: Consumer Relations  
Atención a: Servicio de Atención al Cliente  
À l'attention de: Service à la clientèle

### Online Registration - Registro online - Enregistrement en ligne:

[www.yardistrystructures.com/warranty](http://www.yardistrystructures.com/warranty)

Hours/ Heures/ Horas: 8:30 am - 5:00 pm EST  
(excl. holidays/ hors jours fériés/ excepto los días festivos)

English and French Spoken / Anglais et français parlés / Inglés y francés hablado

Yardistry would like to say "Thank you" for your time and feedback.

Yardistry quiere "Agradecerle" por su tiempo y su opinión.

Yardistry aimerait vous remercier d'avoir pris le temps de répondre au sondage.