

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

1. Do not use these products outdoors unless marked suitable for outdoor use.
2. When products are used outdoor applications, connect the product to Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
3. Do not mount or place near gas or electric heaters, fireplace, candles, or other similar sources of heat.
4. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
Install only using the mounting means provided.
5. Do not let lamps rest on the supply cord or on any wires.
6. Do not hang objects from the cord, wire, or light string.
7. Do not use this product for other than its intended use.
8. Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
9. Do not cover the product with cloth, paper or any material not part of the product when in use.
10. Read and follow all instructions that are on the product or provided with the product.

SAVE THESE INSTRUCTIONS

CAUTION:

1. To reduce the risk of fire use only type S LED lamps, 1 Watt maximum
2. To reduce the risk of fire do not deliberately reposition either lampholder contact.



MODEL NUMBER: 72001

The lighting string is rated at 220-240v ~, 50Hz, 24 Watts.
It is provided with 24 lampholders and 1 Watt, S Type LED lamps.

CAUTION: RISK OF ELECTRIC SHOCK,

Do not use with extension cord near water or where water may accumulate.
Keep lamps at least 16 feet (4.88m) from pools and spas. Keep plugs and receptacles dry.
Do not submerge.

Disconnect power at source prior to wiring, replacing light bulbs or servicing in any way.
The light string kits are supplied with an attached three prong plug that will only fit into a three prong outlet.
Do not alter the plug.

REPLACING LIGHT BULBS

WARNING – RISK OF ELECTRIC SHOCK!! Disconnect power at source prior to replacing light bulbs.

For outdoor String Lights, do NOT replace light bulbs during rain or when wet.


1. Replace light bulbs only during dry and calm weather conditions.
2. Unscrew existing bulbs by lightly holding the socket in one hand and twisting the bulb counterclockwise. Bulbs may be tight in the sockets. This is normal to prevent moisture from getting into socket.
3. Replace with medium base light bulbs. Screw bulb into socket clockwise until top of socket forms a tight seal around the light bulb and bulb makes solid contact with socket. Suitable for Incandescent, CFL, or LED light bulbs.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interfer-


ence to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.
This Class B digital apparatus complies with Canadian CAN ICES-005 (B) / NMB-005 (B).

CONNECTING STRING LIGHTS




INSTALLATION METHODS

1. Using a Guide Wire with S-hooks or zip ties (not included)



2. Attached to a Structure



DRAWINGS NOT TO SCALE

CONNECTING MULTIPLE SETS

USING INCLUDED LED BULBS

MAXIMUM WATTAGE RANGE	NUMBER OF LIGHT STRINGS
1 WATT	20 SETS

BULB LIFE: 15,000 HOURS

CAUTION: DO NOT EXCEED 690 WATTS

The above chart and wattages only apply to included 1 watt LED bulbs. If using incandescent bulbs see chart on right.



USING INCANDESCENT BULBS NOT INCLUDED

MAXIMUM WATTAGE RANGE	NUMBER OF LIGHT STRINGS
7.5 WATT	12 SETS
8-9 WATT	10 SETS
10-11 WATT	8 SETS
12-15 WATT	6 SETS

DO NOT EXCEED 2300 WATTS ALL SETS COMBINED.

PROTECTION FROM WATER CONTACT

The bulb of the following lamp types is suitable for water contact, e.g. drips, splashing, etc., and therefore requires no additional luminaire protection:

- GLS – All lamps with a rated wattage of 15W or below;
- GLS – coloured lamps with a rated wattage of 25W or below;
- PAR38 – All wattages.

All other lamps within the scope of this standard should be protected from water contact, e.g. drips, splashing, etc., by the luminaire if rated at IPX1 or higher.