


USER MANUAL



"

Thanks for Choosing **DREO!**

Your support means the world to us. We hope you enjoy our product as much as we did creating it.

CONTENTS

01

IMPORTANT SAFETY INSTRUCTIONS

1-6

03

CONNECTING YOUR HUMIDIFIER

11

05 CLEANING AND

MAINTENANCE

16-22

07

DREO CUSTOMER CARE

25-26

02

KNOWING YOUR HUMIDIFIER

7-10

04

USING YOUR HUMIDIFIER

12-15

06

TROUBLESHOOTING

23-24

IMPORTANT SAFETY INSTRUCTIONS





READ ALL CAUTIONARY MARKINGS ON THE APPLIANCE AND SAFETY INSTRUCTIONS IN THE USER MANUAL BEFORE USE.



DO NOT touch or hold the mains plug with wet hands.



DO NOT block or cover the nozzle while in operation.





Do not use the humidifier near flammables and combustibles.



DO NOT let children or pets play with this appliance.

General Safety

- 1. The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 2.Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock, or personal injury. Ensure that the fan is switched off from the supply mains before removing the guard.

Operation Safety

- Place the appliance on a flat, dry surface before use.
- 2. Never leave water in the reservoir

when the appliance is not in use.

3.Do not permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the humidifier down. If the humidifier output volume cannot be turned down, use the humidifier intermittently.

Do not allow absorbent materials,

Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.

Do not immerse in water and any other liquids.

5.**Do not** use the appliance until the base is installed.

6.Do not insert your fingers, pencil and any other objects into the grilles while in operation.

7.**Do not** dismantle, repair, or modify. All servicing should be performed by

qualified personnel.

8. Warning: Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks

when the water is not renewed and the tank is not cleaned properly every 3 days.

Electricity Safety

- 1. Make sure that the voltage of your electricity supply is the same as that indicated on the appliance.
- 2.Unplug the appliance during filling and cleaning.
- 3.Do not operate any humidifier with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- 4.Do not run cord under carpeting.
 Do not cover cord with throw rugs,
 runners, or similar coverings. Do not
 route cord under furniture or
 appliances. Arrange cord away from
 traffic area and where it will not be
 tripped over.
- 5.WARNING: To reduce the risk of fire or electric shock, do not use this humidifier with any solid-state speed control device.
- 6.WARNING If the supply cord is

damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



Correct Disposal of this product

This marking indicates that this product should not be disposed of with other household waste throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources To return your used device, please use the return and collection system or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

FOR HOUSEHOLD USE ONLY READ AND SAVE THESE INSTRUCTIONS

Gentle Reminder



Check the appliance regularly and refer to TROUBLESHOOTING or contact our customer support if it shows any of the following signs:

- Power cord or plug is damaged.
- Loud noise, unusual smell or excessive heat.


Specifications


Model No.	DR-HHM003S
Input	AC 220-240V 50Hz
Rated Power	26W(Cool) 280W(Warm)
Water Tank Capacity	6L


KNOWING YOUR HUMIDIFIER


02

Package Contents









LED Display



















Note:

When humidity levels are below 10%, the display will show "LO". When humidity levels are above 90%, the display will show "HI" When the water is low, the Low Water Level Indicator will flash for 5 seconds then the humidifier will switch to standby.

Control Panel



Auto Mode Button	Turn Auto Mode on Touch the Auto Mode button to increase the target humidity by 5%. (Target humidity ranges from 30% to 90%.) In Auto Mode, mist level is adjusted according to your target humidity.
Warm Mist Button	Turn warm mist off/on Note: The warm mist is turned on by default.
Brightness Control Button	Brightness Control Switch the Humidity Indicator Lights and screen brightness between 100%/50%/off.
Timer /WiFi Settings	Select to set a timer (0-12h) Long press for 5 seconds to enter WiFi settings.

Note: Long press 1 and 2 for 5 seconds to turn off/on WiFi connection and enter/exit Low Power Standby Mode.

Humidity Indicator Light



Humidity Light Color	Humidity Level
Yellow	≤30%
Green	31% - 60%
Blue	≥61%

The LED indicator will change according to your room humidity level.

Note: Be aware that high humidity levels may encourage the growth of biological organisms in the environment.

CONNECTING TO YOUR HUMIDIFIER



Before connecting the appliance to your mobile device, please scan the QR code on the left or go to the app store and search "DREO", then select and download the app.





Look for "HM813S" when connecting your new humidifier.



You can use the Dreo app to connect your smart appliance to **Amazon Alexa** or **Google Home.** Please follow the in-app instruction to set up your voice assistant.

NOTE: You must create a DREO account to access voice assistants.

- 1 Launch DREO and sign in or create account by following in-app instructions.
- 2 Enable Bluetooth on your mobile device and plug in your humidifier.
- Hold the Timer Mode button of for 5 seconds to start WiFi connection settings.

 (Tip: The WiFi icon so will keep flashing when pairing.)
- Tap + Add Device and select HM813S.
- 5 Follow in-app instructions to complete WiFi connection.
- You're now ready to control the appliance on your App.


 (Tip: To restart connection settings, hold the good button again for 5 seconds.)

 Long press 10s the power button (1) to unpair WiFi and restore factory settings).

USING YOUR HUMIDIFIER

Before Use

When using your humidifier for the first time, remove the wraps and follow the steps below.




Make sure the water cartridge is installed correctly and the yellow label has been removed.



Detach the cover and water tank from the humidifier and clean thoroughly.



Fill the tank with water, making sure the water doesn't pass the MAX line.



Put the water tank back in place and close the top cover.



⑤ Place the humidifer on a flat, level surface, keeping at least 30 cm / 12 inch away from walls or any major obstacles.

ATTENTION:

- It is recommended to add purified or distilled water to prevent white powder residue from forming.
- Do not add essential oil into the water tank to avoid damage to the tank.
- Do not place the humidifier on the carpet or floor directly.
- Direct the mist away from walls, furniture and electrical appliances.
- Empty and clean the humidifier before storage. Clean the humidifier before next use.
- It is recommended to place a water-resistant mat under the humidifier to catch spills and droplets.

General Operations


- 1 Plug the humidifier into an electrical outlet.
- 2 Touch \bigcirc to turn on/off the humidifier.
- $\mbox{\bf 3}$ Touch $\underline{\mbox{\it SS}}$ to switch between Low, Medium and High mist settings.

Cool/Warm Mist Level Indicator

Mist Level	Display
Low	
Medium	
High	

The indicator is **blue** in cold mist mode and turns **orange** in warm mist mode.

Adjust the direction of the mist with the 360° rotating nozzle.



Warm Mist

Mist Level	Mist Temperature(±3°C)
Low	45°C
Medium	50°C
High	55°C



CAUTION:

Mist may be hot in warm mist mode. Do not place your bare hands, face, or other exposed skin over the nozzles while using warm mist.

Auto Mode

In Auto Mode, mist level is adjusted according to your target humidity.


- Touch the (A) button to turn on Auto Mode.
- Touch the (A) button to increase the target humidity by 5%. (Target humidity ranges from 30% to 90%.)

Timer

- Touch the (L) button to select a timer (0-12h).
- When the timer is turned off, the LED screen will display "OH".

Adding Essential Oil





Push to open the aroma pad tray.





Open the lid on the side you want to add the essential oil.





Add 5-10 drops of essential oil on the aroma pad.




Put the aroma pad tray back in place.

Note:

- $\,^{\star}\!$ Add essential oils on the aroma pad only. Do not add into the water tank or any other places,
- •The scent may be soft, this humidifier is not intended to work as an aroma diffuser.
- The scent level cannot be adjusted.
- The tray contains two separate compartments. Leave open the compartment that has the scent you like.
- ·If the aroma pad becomes too stiff, it needs to be replaced.

Absorption Pads



The mineral absorption pads help reduce mineral buildup (scale) inside the humidifier, especially on the heating element.

Note:

The absorption can be reused after cleaning, but it is recommended replace it regularly.

CLEANING AND MAINTENANCE






- Always turn off and UNPLUG the humidifier before any cleaning or maintenance.
- . Do not clean the main body under running water.
- Do not let water splash into the air outlets.
 - Do not use any chemical agents when cleaning the humidifier.
 - Store in a cool, dry place and cover it to protect from dust.
- Do not overfill the humidifier due to the potential risk of electric shock.

Filling & Refilling

Empty the tank and refill every third day. Before refilling, clean it with fresh tap water or cleaning agents if required by the manufacturer. Remove any scale, deposits, or film that has formed on the sides of the tank or on interior surfaces, and wipe all surfaces dry.





Detach the water tank from the base.





Remove the mist tube and rinse it with warm water.



Take out the water tank cover, drain any remaining water from the tank and the base. Note: If you've used the warm mist setting, use caution in case the water is still hot.





Rinse the tank with lukewarm water.



Gently clean the base with a soft cloth or the included cleaning brush.




Wipe the tank clean with a soft, damp cloth.






Fill the tank with room-temperature water. Do not fill with hot water.





Attach the mist tube to the back of the base.





Attach the water tank to the base, replace the top cover.

Descaling

RECOMMENDED ONCE A MONTH



Drain any remaining water from the tank and the base.

2



Fill the tank with a solution of bleach and water (one teaspoon of bleach for each gallon of water.) Replace the tank cover and shake around the tank





Attach the water tank to the base. Let it sit for 15-20 minutes.






Remove the water cartridge. Note: Do not remove the water valve below the cartridge.



Remove the mist nozzle, mist tube, hot/cold mist mixer, noise silencer and float.



Remove the tank and detach the cover, drain any remaining solution from the tank and the base. Rinse the tank with water until the bleach smell is gone.






Clean the base with a soft cloth or the included cleaning brush to remove excess of mineral deposits Make sure all parts are dry before reassembling your humidifier.

Cleaning the aroma pad tray

RECOMMENDED ONCE A WEEK




Push to open the aroma pad tray at the back of the base to pull it out.



Rinse with water and place back into the base.


Reassembling





Place the water cartridge back into the tank. Make sure the water cartridge clicks in place.





Align the float with the cavities on both sides and push downwards till you hear the "click"





Place the absorption pad and the noise silencer back to the PTC heater.






Place the mist tube on top of the hot/cold mist mixer. Make sure the two parts click in place.





Place the mist tube and the hot/cold mist mixer over the base.






Place the aroma pad back into the aroma box.

Is Your New Humidifier Leaking?




Make sure to remove the protective foam.



Align the float with the cavities on both sides and push downwards till you hear the "click".




Remove any particles or hair blocking the water valve.



Make sure the humidifier is placed on a flat surface.

Contact Customer Service If...



The water valve is not flat or the tank leaks water when refilling.



Your water tank has leakage due to prolonged use of essential oils.

If your humidifier keeps leaking water, please contact customer support (see page 26).

TROUBLESHOOTING

My humidifier does not work.

- Make sure that the cord is connected to a powered outlet and the mains voltage corresponds with the voltage indicated on the humidifier.
- 2. The humidifier will shut down automatically in the event of low water.
- 3. Check the water tank is installed properly.

My humidifier is not misting.

- 1. Please check whether the air inlet is blocked.
- 2. The water in water reservoir is nearly used up.
- 3. Your room might have too much ventilation. Please close doors and windows.

The mist produces an unpleasant smell.

- 1. Use purified or distilled water only. It is not recommended to use tap water.
- 2. Change water regularly to avoid dirty water accumulation.
- 3. Clean the humidifier and keep it dry for 12 hours with the cover detached.
- 4. Clean the aroma pad tray, change the aroma pad.

Water leaks from my humidifier.

- 1. Make sure the silicone sealing ring around the water outlet valve is secure.
- 2. Avoid running the humidifier in a room with over 60% relative humidity.
- 3. Wipe any excess water.
- 4. Do not shake the humidifier
- 5. Make sure to place the humidifier on a flat, level surface.
- Check the water tank for leaks. If there are leaks, contact Customer Support (see page 26).

Humidifier uses water too quickly.

- 1. The humidifier uses up water based on the environmental temperature and humidity. If your environment is cold and/or dry, the humidifier will run out of water faster.
- 2. Using the warm mist function will use up water faster.
- 3. Switch to Auto Mode to adjust mist level based on your room's humidity.

White dust appears around the humidifier.

- 1. It is recommended to purchase the DREO replacement cartridge that cartridge out white dust.
- 2. Using purified or distilled water to fill the humidifier. Avoid using water with high mineral content, such as tap water.
- 3. Clean the humidifier regularly (see Cleaning & Maintenance, page 16).

- 1. Press \$55 to adjust the mist temperature from 45°C to 55°C.
- 2. Allow the humidifier to heat up for about 5-10 minutes to produce warm mist.
- 3. Clean and descale the heating element (see Cleaning & Maintenance, page 16).

Humidity in the room remains unchanged.

- 1. Use a higher mist level setting.
- 2. Depending on your environment, the humidifier may take longer to humidify your air.
- **3.** The room may be larger than the humidifier's effective range. If the room is larger than 215–430 ft² / 20–40 m², the humidifier will not be as effective.

If your problem is not listed or still persists, contact our Customer Support (see page 26).

DREO CUSTOMER CARE

07

24-MONTH LIMITED WARRANTY

What is Covered

DREO warrants to you that your product will be free from original defects in materials and workmanship for a period of twenty four (24) months from the date of your purchase, when you use your product for intended purposes in accordance with this User Manual.

Please retain your proof of purchase. If you do not retain your proof of purchase, your warranty will start two (2) months from the date of manufacture printed on your product label.

What is Not Covered

This limited warranty only applies to the original purchaser of your product and is non-transferable. This warranty is only valid if your product is used in the country in which you originally purchased it. In addition, this warranty will not apply, and DREO will not be liable for any costs, damages, or repairs, in connection with any of the following:

- Accidents or use of your product with inappropriate force:
- Damage or destruction caused by wrong voltage or unstable electric current;
- · Normal wear and tear:
- Careless operation or handling, misuse, abuse, neglect, and/or failure to maintain or use your product in accordance with this User Manual:
- · Any partially or completely altered, modified and/or dismantled products;
- Reduction in battery discharge time due to battery age or use (as applicable):
- Products with altered or removed serial numbers:
- · Clearing any blockages from the product;
- Purchases from retailers and distributors not authorized by DREO to sell this product;
- Defects caused by or resulting from damages from shipping or handling by any third party not authorized by DREO to ship or handle your product; or
- Defects caused by or resulting from repairs, service, improper maintenance, or alteration to your product or any of its components by anyone other than a repair person authorized by DRFO

Any service and customer support that DREO provides to you under this limited warranty will not extend the duration of this limited warranty.

Warranty Limitations and Exclusions

ANY IMPLIED WARRANTIES RELATING TO YOUR PRODUCT, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THE LIMITED WARRANTY SET FORTH ABOVE AND ARE OTHERWISE DISCLAIMED.

THIS LIMITED WARRANTY SHALL BE THE SOLE REMEDY OF THE PURCHASER OR USER OF THE PRODUCT, AND DREO SHALL NOT BE LIABLE FOR AN ALLEGEDLY DEFECTIVE OR DAMAGED PRODUCT EXCEPT TO REPAIR OR REPLACE IT IN ACCORDANCE WITH THIS LIMITED WARRANTY. DREO WILL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, INDIRECT, CONTINGENT, OR CONSEQUENTIAL DAMAGES OR LOSSES OF ANY NATURE THAT YOU MAY INCUR IN CONNECTION WITH YOUR PURCHASE OR USE OF YOUR PRODUCT.

Some jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you also may have other rights which vary from jurisdiction to jurisdiction.

Limited Remedies

If your product fails because of an original defect in material and/or workmanship during the warranty period, DREO will repair or replace (in DREO's sole discretion) your product. To obtain warranty service on your product, contact us at uk-support@dreo.com for further instructions.

IN THE EVENT OF AN ORIGINAL DEFECT IN MATERIAL AND/OR WORKMANSHIP, TO THE EXTENT PERMITTED BY LAW, THE REMEDIES SET FORTH IMMEDIATELY ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES.

Model No.: DR-HHM003S Rev_1,1_UK

We're Here to Help!



uk-support@dreo.com



www.dreo.com



Shenzhen Hesung Innovation Technology Co., LTD



26F, Bldg A7, Creative City, Shenzhen, China









MADE IN CHINA



www.dreo.com

Looking for help?

Contact us to get expert support.



