

10' x 8' Workshop

IMPORTANT, RETAIN FOR FUTURE REFERENCE;
READ CAREFULLY

This buildings is pressure treated to ensure longevity of all timber components and to protect against rot. This may leave a colour difference on some parts that will even out as the moisture content stabilises. This will not require additional treatment.

- Timber is a natural material. It will shrink and swell as a result of varying moisture content.
- Please keep all plastic bags and small parts away from children
- The roof of this building is not a load bearing structure.
- This product must be built on a solid level base.
- Please use suitable gloves when handling glass.


Technical Help line: **0333 7777 089** 8.30 am to 5.00 pm Monday to Friday.

Check all parts prior to assembly

In line with your statutory rights, please check all parts prior to assembly, as assembly of damaged parts may be deemed to be acceptance and this may affect the remedies you are entitled to. If the product is not constructed in accordance with the instructions, or is altered in anyway (e.g. painted), the manufacturer cannot be held liable for any resulting damage.

Fixing Pack (TPA812DDFP)

Not to Scale



REQUIRED TOOLS : (NOT SUPPLIED)






Important : Assembly of this shed requires a minimum of two adults.



Must Pre drill for each screw used.


TPA810DD PARTS LIST






ATTENTION:
1. THE ROOF IS NOT LOAD BEARING.
2. TAKE CARE WHEN CUTTING THE ROOF FELT.

Place each roof section on top of the building so that they are flush with the end panels and in line with the apex. Screw up through the end panels framework into the roof battens as shown using 1x50mm screw. Where the roof sections sit on the apex, screw down through the roof slats and framing into the truss using 2 x 70mm screws for each roof panel.




Unroll the felt and place a section on each eaves so that there is a 50mm overhang on each edge as shown. Fix this to the roof using felt nails spaced in 150mm intervals. Cut and fold the corners securing with a single felt nail for each.

Place the remaining sections as shown making sure that they overlap the others. Again secure each sheet in place using felt nails spaced in 150mm intervals.




Place the barge boards against the ends of the building so that they are flush with the overhang of the roof and in line with the top. Fix each in place using 3x30mm screws.

Place the finials over the join making sure they are centred. Secure in place using 2x40mm screws for each.



Place the 1754mm batten against the framing of the slave door. Make sure that it is tight and flush and that the batten will sit neatly between the top and bottom of the door entrance. Fix this to the door by nailing through the front of the door into the batten using 4 x 30mm nails.

Fix a turn button to the top and bottom of the batten using 1x30mm screw for each.




Place the lock block against the inside and middle of the door as shown. Fix this in place using 2x40mm


Place the lock against the framing as shown and using a pencil, mark the position where the key hole and spindle will be before drilling the hole.

For the key hole we recommend a whole 25 x 10mm.


Fix the lock and handles in place using the screws provided.




Fix the escutcheon over the key hole using the small screws provided




Fix the 677mm strip to the framing between the windows. Use 2x30mm Nails




Before glazing the windows decide on the positions of the two fixed windows and place the window frame into the panel. Fix it to the framing using 8 x 40mm screws, making sure that the screw heads are flush. (Pre-drill)



For the **opening windows** fix two cranked hinges to the top of the window so that it sits in the rebate. Fix the smaller section of the hinge to the window using 2 x 25mm screws for each. Open up the hinges and fix the remaining section of each hinge to the top of the window panel using another 3 x 25mm screws for each hinge.



For each window, place the acrylic sheet inside the window frame and position the beading so that each section fits flush and keeps the sheet tight. Fix each piece using 3 x Panel Pins



Place and fix the Casement Stay centrally against the inside of the opening window and make sure it is offset at least 12mm from the top of the frame so as not to hit the acrylic sheet. Fix in place using 2 x 25mm screws.

Mark the position of the holes of the casement stay when the window is closed before fixing the pins in place using the 25mm screws provided.

Biocidal Product Regulation (EU 528/2012) Article 58 Information

This article contains timber treated with Celcure AC-500, incorporating biocidal products to give protection against wood destroying insects & wood rotting fungi.

Contains: Basic copper carbonate (Copper (II) carbonate – Copper (II) hydroxide (1:1)), Boric acid, Benzalkonium chloride.

Wear gloves when handling freshly treated wood. Avoid breathing dust when cutting treated or untreated wood. Dispose of off-cuts responsibly – do not burn.

Maintenance.

Regularly check that all fixings are secure.

Regularly check the quality of the roofing felt and that it is free of holes and splits.